Low voltage electrical distribution

Micrologic

Control units 5.0 H, 6.0 H and 7.0 H

User manual 01/2009





Contents

Discovering Micrologic H	4
Identification	4
Presentation Setting procedure	5 6
Setting Micrologic 5.0 H using the dials	8
Setting Micrologic 6.0 H using the dials	9
Setting Micrologic 7.0 H using the dials	10
Selecting the type of neutral protection	11
Main menus Metering	12 14
History, maintenance and setup	18
Protection	20
Overview of functions	22
Current protection	22
Voltage protection	28
Other protection Load shedding and reconnection	29 30
Measurements	31
Harmonic measurements	33
Alarms	44
Optional M2C and M6C contacts Event histories	45 46
LEDs and display screens	47
COM communications option	49
Setup	50
Setting up the optional M2C / M6C contacts	50
Setting up the Micrologic control unit	52
Setting up the metering functions Setting up the COM communications option	55 58
Protection settings	60
Fine adjustment of the long-time I ² t, short-time and	00
instantaneous settings using the keypad	60
Fine adjustment of the long-time Idmtl, short-time and	
instantaneous settings using the keypad	61
Fine adjustment of the ground-fault and earth-leakage protection setting using the keypad	62
Setting the neutral protection	63
Setting the I \(\preceq\), I unbal, \(\bar{I}\)max, U min, U max, U unbal, rP max, F min, F max, and phase-rotation protection functions	
using the keypad	64
Setting load shedding / reconnection	66
Metering	68
Current measurements	68
Voltage measurements Power measurements	71 73
Energy measurements	75
Harmonic measurements	76
Frequency measurements	82
Maintenance	84
Resetting fault indications Viewing the event histories	84 85
Viewing the event histories Operation counter and contact-wear indicator	86
Checking/replacing the battery	87
Tests	88

Schneider Electric

Contents

Technical appendix	90
Tripping curves	90
Voltage measurements	92
Zone selective interlocking (ZSI)	94
Power supply	95
Changing the long-time rating plug	97
Thermal memory	98
Data available via the COM communications option	99
Threshold and time-delay settings	101
Other settings	104
Measurement setting ranges and accuracy	105
Power factor sign conventions	106
Index	108

04443728AA - 01/2009 Schneider Flectric

Identification

All Masterpact NT and NW circuit breakers are equipped with a Micrologic control unit that can be changed on site.

Control units are designed to protect power circuits and connected loads.


They offer current, voltage, frequency, power and energy measurements.

The functions provided by Micrologic 5.0 H, 6.0 H and 7.0 H control units optimise continuity of service and power management in your installation.

Micrologic 5.0 H

Selective protection + Idmtl, power measurements and additional protection





Selective protection + Idmtl

Micrologic 5.0 H X Y 7

X: type of protection

- 2 for basic protection
- 5 for selective protection
- 6 for selective + ground-fault protection
- 7 for selective + earth-leakage protection

Y: version number Identification of the control-unit generation: "0" signifies the first generation.


Z: type of measurement

- A for "ammeter"
- P for "power meter"
- H for "harmonic meter"
- no indication = no measurements

Micrologic 6.0 H

Selective protection + Idmtl + ground-fault protection, power measurements and additional protection






Micrologic 7.0 H

Selective protection + Idmtl + earth-leakage protection, power measurements and additional protection





Presentation

- 1 top fastener
- 2 terminal block for external connections
- 3 housing for battery
- 4 screw for long-time rating plug
- 5 long-time rating plug
- 6 cover opening point
- 7 protective cover
- 8 lead-seal fixture for protective cover
- 9 infrared link with communications interfaces
- 10 connection with circuit breaker
- 11 bottom fastener

Indications


- 12 LED indicating long-time tripping
- 13 LED indicating short-time or instantaneous tripping
- **14** LED indicating ground-fault or earth-leakage tripping
- 15 LED indicating additional-protection or auto-protection tripping
- 16 graphics display
- 17 button for reset of fault-trip LED reset and battery test


Navigation


- 18 access button to the "Metering" menu (1)
- 19 access button to the "History, maintenance and setup" menu (1)
- 20 access button to the "Protection" menu (1)
- 21 button used to scroll down or reduce the displayed value
- 22 button used to scroll up or increase the displayed value
- 23 button used to select or confirm a choice


Adjustment dials

- 24 long-time current setting Ir
- 25 long-time tripping delay tr
- 26 short-time pickup Isd
- 27 short-time tripping delay tsd
- 28 instantaneous pickup li
- 29 ground-fault pickup Ig
- 30 ground-fault tripping delay tg
- 31 earth-leakage pickup l∆n
- 32 earth-leakage tripping delay ∆t
- 33 LED indicating an overload
- **34** test button for ground-fault and earth-leakage protection
- 35 test connector
- (1) These buttons include a LED indicating the active menu.













Micrologic 5.0 H control unit







Micrologic 7.0 H control unit





Setting procedure

Dials

- Dials are used to set Micrologic H protection thresholds and tripping delays for overloads, short-circuits, ground faults and earth leakage.
- If the set thresholds are overrun, these protection functions systematically trip the circuit breaker.

Settings using the dials





Buttons

- Buttons on the keypad are used for fine adjustments of the protection thresholds and tripping delays for overloads, short-circuits, ground faults and earth leakage. The value previously set using a dial automatically becomes the maximum value for the keypad settings.
- They may also be used to activate other factorydisabled protection functions available on Micrologic H. These other protection functions are not accessible via the dials.

With the protective cover open, make all the necessary settings for your control unit.

All fine adjustments are permanently stored in memory, unless the setting is modified using the adjustment dial.

For remote settings using the communications option, see the "Remote settings" section in the "Com setup" menu under "History, maintenance and setup".

■ Open the protective cover.

- Make the necessary settings using the dials
- The screen automatically displays the relevant curve
- Check the set value on the screen, in absolute value in amperes (A) and in seconds (s).

Settings using the keypad

- The buttons under the screen may be used for fine adjustments of the settings made using the dials.
- All the settings not available via the dials are made in the same manner, using the keypad.


Caution!

A new overload (long-time) or short-circuit (short-time and instantaneous) protection setting made using one of the dials:

- deletes all the fine adjustments previously made using the keypad for the overload (long-time) and short-circuit (short-time and instantaneous) protection
- does not affect the fine adjustments made using the keypad for ground-fault and earth-leakage protection
- does not affect any other settings made using the keypad.

Similarly, a new ground-fault or earth-leakage protection setting made using one of the dials:

- deletes all the fine adjustments previously made using the keypad for the ground-fault and earth-leakage protection
- does not affect the fine adjustments made using the keypad for the overload (long-time) and short-circuit (short-time and instantaneous) protection
- does not affect any other settings made using the keypad.



Setting procedure

With the protective cover closed, it is not possible to set the protection functions. However, it is possible to set metering functions and alarms, as well as view all measurements, settings and histories.


View the settings and measurements



- Close the protective cover for the dials
- Access to the dials is blocked and it is no longer possible to make fine adjustments using the keypad



- If necessary, install a lead seal to protect the settings
- Settings may be viewed at any time using the keypad.




Caution!

If you notice that the tab on the back of the protective cover has been broken off, contact the Schneider Electric after-sales support department to replace the cover.

Setting Micrologic 5.0 H using the dials


Consider a 2000 A circuit breaker.




See pages 22 and 24 for selection of the setting


ranges.


Set the thresholds



Set the time delays









Setting Micrologic 6.0 H using the dials

Consider a 2000 A circuit breaker.





See pages 22 to 26 for selection of the setting ranges.

Set the thresholds



Set the time delays






tg: ground-fault tripping delay

Ig: ground-fault pickup


Setting Micrologic 7.0 H using the dials

Consider a 2000 A circuit breaker.





See pages 22 to 26 for selection of the setting ranges.

Set the thresholds




Set the time delays





Selecting the type of neutral protection



Caution! With the 4P 3D setting, the current in the neutral must not exceed the rated current of the circuit breaker.

Selection dial on four-pole circuit breakers

On four-pole circuit breakers, it is possible to select the type of neutral protection for the fourth pole using the three-position dial on the circuit breaker:

- no neutral protection 4P 3D
- half neutral protection 3D + N/2
- full neutral protection 4P 4D


The factory default setting is 3D + N/2.

Main menus

The Micrologic H control unit offers access to the main screen and three menus:

- the main screen displaying the continuous measurement of the phase currents (I1, I2, I3) and the neutral current (IN), if it exists
- the "Metering" menu
- the "History, maintenance and setup" menu
- the "Protection" menu.

Main screen



As long as no functions are activated, Micrologic H control units display in real time the current on the most heavily loaded phase.

The number for that phase is presented in a square.


The current in the neutral is displayed if the neutral CT is set as internal or external (see "Ineutral (A)" settings in the "Current protection" menu).

When a menu button is pressed, a presentation screen is displayed and the green LED on the button goes ON.

"Metering", "History, maintenance and setup" and "Protection" menus

■ "Metering" menu





- press the or button to return to the main screen
- press the button to return to the previous screen
- □ whatever the screen displayed, if no further action is taken, the system returns to the main screen after a few minutes
- $\hfill\Box$ the LED goes OFF on exiting the menu.

Main menus

■ "History, maintenance and setup" menu



Event history

Contacts M2C / M6C

Micrologic setup

Metering setup

Com. setup

 $\hfill \Box$ press the $\hfill \Box$ or $\hfill \Box$ button to return to the main screen

□ press the button to return to the previous screen

□ whatever the screen displayed, if no further action is taken, the system returns to the main screen after a few minutes

□ the LED goes OFF on exiting the menu.

■ "Protection" menu



Current

Voltage protection

Other protection

Load shedding

Load shedding I

press the or button to return to the main screen

press the button to return to the previous screen

□ whatever the screen displayed, if no further action is taken, the system returns to the main screen after a few minutes

 $\hfill\Box$ the LED goes OFF on exiting the menu.

■ Saving settings



yes

When a setting is made in any of the three menus, the screen used to save the modification(s) may be accessed by pressing one of the three buttons






 $\hfill\Box$ select yes to save the modifications


□ select no to cancel and maintain the previous settings


 $\hfill \square$ this screen remains displayed until yes or no are selected.





U (V)
P (kW)
E (kWh)
Harmonic


















values



up to H31



P (kW)
E (kWh)
Harmonic
F (Hz)

Frequency measurement



History, maintenance and setup

Press the button to select the "History, maintenance and setup" menu.

move the cursor down the screen or decrement a value.

move the cursor up the screen or increment a value.

select an option in a list, confirm a selection or the value of a setting.

indicates that the operator is in the "History, maintenance and setup" menu and returns to the previous screen.

return to the main screen.

Event history

Event history access to the following sections:

Trip The last ten faults recorded history

Alarm The last ten alarms recorded history

Contact Wear of the circuit-breaker main contacts

Number of operations (opening or closing)

M2C / M6C Contacts

wear

Reset

M2C / M6C

Operation

Contacts access to the following sections:

Alarm type

Assignment of a protection alarm to an M2C or an M6C contact

Setup Latching mode for each M2C or M6C contact

Reset of the M2C or M6C contacts

Event history

Contacts M2C / M6C

Micrologic setup

Metering setup

Com. setup

Event history

Contacts M2C / M6C

Micrologic setup

Metering setup

Com. setup

History, maintenance and setup

E71714A

Event history

Contacts M2C / M6C

Micrologic setup

Metering setup

Com. setup

E71715A

Event history

Contacts M2C / M6C

Micrologic setup

Metering setup

Com. setup

Event history

Contacts M2C / M6C

Micrologic setup

Metering setup

Com. setup

Micrologic setup

Micrologic setup



access to the following sections:

Language

Selection of the display language

Date / time

Setting of the date and time

Breaker selection

Indication of the circuit-breaker type

Power sign

Setting the power sign

VT ratio

Select of the primary and secondary voltages on the instrument transformer

System frequency

Indication of the rated system frequency

Metering setup

Metering setup



access to the following sections:

System type

- 3 phases, 3 wires, 3 CTs: method using two wattmeters
- 3 phases, 4 wires, 3 CTs: method using three
- 3 phases, 4 wires, 4 CTs: method using three wattmeters with measurement of the neutral current.

Current demand

Selection of the calculation method and setting of the time interval for the calculation

Power demand

Selection of the calculation method and setting of the parameters for the calculation

Sign convention

Setting of the sign convention for the power factor and reactive power, i.e. IEEE, IEEE alternate or IEC (see page 106 to determine the sign convention)

COM communications-option setup

Com. setup



access to the following sections:

Com. parameter Setting of parameters for the COM communications option (address, baud rate, parity)

Remote settings

Authorisation of access to settings via the COM communications option.

Remote control

Authorisation of access to the circuit-breaker ON and OFF commands via the COM communications option.



Press the button to select the "Protection" menu.

- move the cursor down the screen or decrement a value
- move the cursor up the screen or increment a value
- select an option in a list, confirm a selection or the value of a setting
- indicates that the operator is in the "Protection" menu and returns to the previous screen
- return to the main screen

Current protection

Current protection



access to the following sections:

(A)

Fine settings of the long-time I2t, short-time and instantaneous protection functions

(A)dmtl

Fine settings of the long-time Idmtl, short-time and instantaneous protection functions

|≰ (A) Fine settings of the:

- ground-fault (Micrologic 6.0 H)
- earth-leakage (Micrologic 7.0 H) protection functions

Ineutral (A)

Selection of the type of neutral sensor and type of neutral protection

Setting of the I ≠ alarm

unbal (%) Setting of the current-unbalance protection I unbal

11 max (A)

Setting of the maximum-current protection 11 max

12 max (A)

Setting of the maximum-current protection 12 max

13 max (A)

Setting of the maximum-current protection 13 max

IN max (A)

Setting of the maximum-current protection IN max

protection Voltage protection Other protection Load shedding

Load

shedding

Current

Protection

Current protection

Voltage protection

Other protection

Load shedding

Load

shedding

Current protection

Voltage protection

Other protection

Load shedding | Load shedding | P

Current protection
Voltage protection
Other protection
Load shedding | Load shedding | P

Current protection

Voltage protection

Other protection

Load shedding I

Load shedding P

Voltage protection

Voltage protection

Setting of the minimum-voltage protection U min.


Umax (V)

Setting of the maximum-voltage protection U max.


Umax (V)

Setting of the voltage-unbalance protection U unbal.


Other protection



Load shedding depending on current



Load shedding depending on power



I²t long-time protection

For the default values, the setting ranges, increment steps and setting accuracies, see the technical appendix.

The long-time protection function protects cables against overloads. This function is based on true rms measurements.

It is possible to select either I²t long-time protection or Idmtl long-time protection.

I²t long-time protection

Long-time current setting Ir and standard tripping delay tr

Micrologic control unit	Accurac	у	5.0 H	, 6.0 H	and 7.0	Н					
Current setting	Ir = In (*) x		0.4	0.5	0.6	0.7	0.8	0.9	0.95	0.98	1
tripping betweeen 1.05 and 1.20 Ir		other ranges or disable by changing rating plug									
Time setting			0,5	1	2	4	8	12	16	20	24
Time delay (s)	tr at 1.5 x Ir	0 to -30%	12.5	25	50	100	200	300	400	500	600
	tr at 6 x Ir	0 to -20%	0.7 ⁽¹⁾	1	2	4	8	12	16	20	24
	tr at 7.2 x Ir	0 to -20%	0.7 (2)	0.69	1.38	2.7	5.5	8.3	11	13.8	16.6

(*) In: circuit breaker rating (1) 0 to -40%

(2) 0 to -60%

■ It is possible to enhance the Ir setting accuracy (reduced range) or disable the long-time protection function by using a different long-time rating plug. See the technical appendix "Changing the long-time rating plug".

Thermal memory

- The thermal memory continuously accounts for the amount of heat in the cables, both before and after tripping, whatever the value of the current (presence of an overload or not). The thermal memory optimises the long-time protection function of the circuit breaker by taking into account the temperature rise in the cables.
- The thermal memory assumes a cable cooling time of approximately 15 minutes.

Idmtl long-time protection

Idmtl Protection

Long-time current setting Ir and Idmtl tripping delay tr

Micrologic co	ntrol unit	Accuracy	5.0 H	, 6.0 H a	and 7.0	H					
Current setting	Ir = In (*) x		0.4	0.5	0.6	0.7	8.0	0.9	0.95	0.98	1
ripping between 1.05	and 1.20 Ir		other ra	nges or dis	able by ch	anging rati	ng plug				
Γime setting			0,5	1	2	4	8	12	16	20	24
DT											
Time delay (s)	tr at 1.5 x Ir	0 to -20%	0.53	1	2	4	8	12	16	20	24
	tr at 6 x Ir	0 to -20%	0.53	1	2	4	8	12	16	20	24
	tr at 7.2 x Ir	0 to -20%	0.53	1	2	4	8	12	16	20	24
	tr at 10 x Ir	0 to -20%	0.53	1	2	4	8	12	16	20	24
SIT											
Time delay (s)	tr at 1.5 x Ir	0 to -30%	1.9	3.8	7.6	15.2	30.4	45.5	60.7	75.8	91
	tr at 6 x Ir	0 to -20%	0.5	1	2	4	8	12	16	20	24
	tr at 7.2 x Ir	0 to -20%	0.7 (1)	0.88	1.77	3.54	7.08	10.6	14.16	17.7	21.2
	tr at 10 x Ir	0 to -20%	0.7 (2)	8.0	1.43	2.86	5.73	8.59	11.46	14.33	17.19
VIT											
Time delay (s)	tr at 1.5 x Ir	0 to -30%	3.6	7.2	14.4	28.8	57.7	86.5	115.4	144.2	173.1
	tr at 6 x Ir	0 to -20%	0.5	1	2	4	8	12	16	20	24
	tr at 7.2 x Ir	0 to -20%	0.7 (1)	0.81	1.63	3.26	6.52	9.8	13.1	16.34	19.61
	tr at 10 x Ir	0 to -20%	0.7 (2)	0.75	1.14	2.28	4.57	6.86	9.13	11.42	13.70
EIT											
Time delay (s)	tr at 1.5 x Ir	0 to -30%	12.5	25	50	100	200	300	400	500	600
	tr at 6 x Ir	0 to -20%	0.7(1)	1	2	4	8	12	16	20	24
	tr at 7.2 x Ir	0 to -20%	0.7(2)	0.69	1.38	2.7	5.5	8.3	11	13.8	16.6
	tr at 10 x Ir	0 to -20%	0.7(2)	0.7(1)	0.7 (1)	1.41	2.82	4.24	5.45	7.06	8.48
HVF											
Time delay (s)	tr at 1.5 x Ir	0 to -30%	164.5	329	658	1316	2632	3950	5265	6581	7900
	tr at 6 x Ir	0 to -20%	0.7(1)	1	2	4	8	12	16	20	24
	tr at 7.2 x Ir	0 to -20%	0.7(2)	0.7(1)	1.1 ⁽¹⁾	1.42	3.85	5.78	7.71	9.64	11.57
	tr at 10 x Ir	0 to -20%	0.7(2)	0.7(2)	0.7(1)	0.7(1)	1.02	1.53	2.04	2.56	3.07

(*) In: circuit breaker rating

(1) 0 to -40 %

(2) 0 to -60 %

- These curves with different slopes are used to improve:
- □ discrimination with fuses positioned upstream (HV) and/or downstream
- $\hfill\Box$ protection for certain types of loads
- Five types of curves are available:
- □ DT: definite time curve
- □ SIT: standard inverse time curve (I^{0.5}t)
- □ VIT: very inverse time curve (It)
- ☐ EIT: extremely inverse time curve (I²t)
- ☐ HVF: compatible with high-voltage fuses (I⁴t).

■ Neutral protection

Overload protection (long time) for the neutral is disabled if the Idmtl protection function is selected. However, the short-circuit protection (short time and instantaneous) remains operational.

■ Intermittent overloads

As long as the Micrologic H control unit remains supplied with power, the effects of intermittent overloads on cables are calculated. If power is cut, temperature rise in cables is not calculated.

■ Circuit-breaker thermal limit

For certain settings, the Idmtl curves may be limited by the I²t curve when the tripping delay tr is set to 24 seconds or by its thermal memory. The maximum I2t curve remains active for the phases and the neutral even when the Idmtl curves are activated.

Short-time and instantaneous protection

For the default values, the setting ranges, increment steps and setting accuracies, see the technical appendix.

For the characteristics and external wiring of the zone

selective interlocking function, see the technical

appendix on "Zone selective interlocking".

Short-time protection

- The short-time protection function protects the distribution system against impedant short-circuits
- The short-time tripping delay and the I²t ON and I²t OFF options can be used to ensure discrimination with a downstream circuit breaker
- This function carries out true rms measurements.
- Use of I²t curves with short-time protection:
- $\ \square$ l²t OFF selected: the protection function implements a constant time curve $\ \square$ l²t ON selected: the protection function implements an l²t inverse-time curve up to 10 Ir. Above 10 Ir, the time curve is constant.
- Zone selective interlocking (ZSI)

The short-time and ground-fault protection functions enable time discrimination by delaying the upstream devices to provide the downstream devices the time required to clear the fault. Zone selective interlocking can be used to obtain total discrimination between circuit breakers using external wiring.

■ Intermittent faults are taken into account by Micrologic H and may lead to shorter tripping times than those set.

Short-time pickup Isd and tripping delay tsd

Micrologic control unit		5.0 H	5.0 H, 6.0 H and 7.0 H									
Pickup	Isd = Ir x accuracy ± 10 %	1.5	2	2.5	3	4	5	6	8	10		
Time delay (ms)	setting	I ² t Off	0	0.1	0.2	0.3	0.4					
at 10 Ir		I ² t On		0.1	0.2	0.3	0.4					
I ² t On or	tsd (max resettable time)	20	80	140	230	350						
I ² t Off	tsd (max break time)	80	140	200	320	500						

If the "without long-time protection" plug is used and the long-time protection function is disabled, the short-time pickup lsd is automatically multiplied by In instead of Ir as is the standard case.

Instantaneous protection

- The instantaneous-protection function protects the distribution system against solid short-circuits. Contrary to the short-time protection function, the tripping delay for instantaneous protection is not adjustable. The tripping order is sent to the circuit breaker as soon as current exceeds the set value, with a fixed time delay of 20 milliseconds.
- This function carries out true rms measurements.

Instantaneous pickup li

Micrologic control ι	ınit	5.0 H	1, 6.0 H	and 7.	0 H					
Pickup	li = In (*) x accuracy ± 10 %	2	3	4	6	8	10	12	15	OFF

(*) In: circuit-breaker rating

- Circuit breakers have two types of instantaneous protection:
- $\hfill\Box$ adjustable instantaneous protection li
- $\hfill \square$ self-protection.

Depending on the circuit breaker, the OFF position corresponds to the self-protection pickup.

Neutral protection

For the default values, the setting ranges, increment steps and setting accuracies, see the technical appendix.

Three-pole circuit breakers

Protection of the neutral is possible on a three-pole circuit breaker by connecting an external sensor.

Settings are made using the and buttons on the control unit.

Micrologic control unit	5.0 F	I, 6.0 I	land	7.0 H
Setting	OFF	N/2	N	1.6xN

Type of neutral	Description
No neutral protection	The distribution system does not require protection of the neutral conductor.
Half neutral protection	The cross-sectional area of the neutral conductor is half that of the phase conductors. The long-time current setting Ir for the neutral is equal to half the setting value The short-time pickup Isd for the neutral is equal to half the setting value The instantaneous pickup Ii for the neutral is equal to the setting value
	■ For ground-fault protection (Micrologic 6.0 P), pickup Ig for the neutral is equal to the setting value.
Full neutral protection	The cross-sectional area of the neutral conductor is equal to that of the phase conductors. The long-time current setting Ir for the neutral is equal to the setting value The short-time pickup Isd for the neutral is equal to the setting value The instantaneous pickup Ii for the neutral is equal to the setting value For ground-fault protection (Micrologic 6.0 P), pickup Ig for the neutral is equal to the setting value.
Oversized neutral protection	In installations with a high level of third-order harmonic currents (or multiples thereof), the current in the neutral conductor may exceed that of the phase currents under steady-state conditions The long-time current setting Ir for the neutral is 1.6 times that of the setting value The short-time pickup Isd for the neutral is 1.6 times that of the setting value, but may not exceed 10 In to limit transients and self-protect the installation The instantaneous pickup Ii for the neutral is equal to the setting value For ground-fault protection (Micrologic 6.0 P), pickup Ig for the neutral is equal to the setting value.

Four-pole circuit breakers

The initial protection setting is made using the dial on the neutral pole of the circuit

The and buttons on the control unit may then be used for a more precise setting. The dial setting constitutes the upper limit for adjustments using the keypad.

Micrologic control unit	5.0 H	, 6.0 H	and 7.0 H
Setting	OFF	N/2	N

Type of neutral	Description
No neutral protection	The distribution system does not require protection of the neutral
Half neutral protection	The cross-sectional area of the neutral conductor is half that of the phase conductors. The long-time current setting Ir for the neutral is equal to half the setting value The short-time pickup Isd for the neutral is equal to half the setting value The instantaneous pickup Ii for the neutral is equal to the setting value
Full neutral protection	The cross-sectional area of the neutral conductor is equal to that of the phase conductors. The long-time current setting Ir for the neutral is equal to the setting value The short-time pickup Isd for the neutral is equal to the setting value The instantaneous pickup Ii for the neutral is equal to the setting value.

25

04443728AA - 01/2009 Schneider

Ground-fault and earth-leakage protection

For the default values, the setting ranges, increment steps and setting accuracies, see the technical appendix.

Ground-fault protection on Micrologic 6.0 H

■ An ground fault in the protection conductors can provoke local temperature rise at the site of the fault or in the conductors. The purpose of the ground-fault protection function is to eliminate this type of fault.

■ There are two types of ground-fault protection.

Туре	Description
Residual	■ The function determines the zero-phase sequence current, i. e. the vector sum of the phase and neutral currents (depending on the type of installation)
Source Ground Return	 Using a special external sensor, this function directly measures the fault current returning to the transformer via the earth cable It detects faults both upstream and downstream of the circuit breaker The maximum distance between the sensor and the circuit breaker is ten metres.

■ Ground-fault and neutral protection are independent and can therefore be combined.

Ground-fault pickup Ig and tripping delay tg

The pickup and tripping-delay values can be set independently and are identical for both the residual and "source ground return" ground-fault protection functions.

Micrologic control unit			6.0 H								
Pickup	Ig = In (*) x accuracy ±10 %		Α	В	С	D	E	F	G	Н	J
	In ≤ 400 A		0.3	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
	400 A < In ≤ 1200 A		0.2	0.3	0.4	0.5	0.6	0.7	8.0	0.9	1
	In > 1200 A		500 A	640 A	720 A	800 A	880 A	960 A	1040 A	1120 A	1200 A
Time delay (ms)	settings	I ² t Off	I ² t Off	0	0.1	0.2	0.3	0.4			
at In or 1200 A		I ² t On		0.1	0.2	0.3	0.4				
I ² t On or	tg (max resettable time)		20	80	140	230	350				
I ² t Off	tg (max. break time)		80	140	200	320	500				

(*) In: circuit-breaker rating

Earth-leakage protection on sur Micrologic 7.0 H

- The earth-leakage protection function primarily protects people against indirect contact because an earth-leakage current can provoke an increase in the potential of the exposed conductive parts. The earth-leakage pickup value $I\Delta n$ is displayed directly in amperes and the tripping delay follows a constant-time curve.
- An external rectangular sensor is required for this function
- This function is inoperative if the long-time rating plug is not installed
- $\hfill\Box$ $\hfill \hfill \hfi$
- □ ☐ C-component withstand class A up to 10 A.
- If the optional external voltage-measurement input is used, a 24 V DC external power supply must be connected to Micrologic H (terminals F1-, F2+).

Pickup value I∆n and tripping delay ∆t


Micrologic control unit		7.0 H									
Pickup (A)	I∆n accuracy 0 to -20 %	0.5	1	2	3	5	7	10	20	30	
Time delay (ms)											
settings	Δt (max resettable time)	60	140	230	350	800					
	Δt (max. break time)	140	200	320	500	1000					

I \(\frac{1}{2} \) Alarm, current unbalance, maximum current

For the pickup and dropout thresholds and time delays, see the technical appendix.

Operating principle

protection tripped by a maximum value




- 1: pickup threshold
- 2: pickup time delay
- 3: dropout threshold
- 4: dropout time delay
- For protection tripped by a maximum value, it is possible to set:
- □ a pickup threshold (1) that activates an alarm, a contact and/or tripping
- ☐ a pickup time delay (2) that steps in when the pickup threshold (1) is reached
- □ a dropout threshold (3) corresponding to deactivation of the alarm and/or contact
- □ a dropout time delay (4) that steps in when the dropout threshold (3) is reached
- The dropout threshold is always less than or equal to the pickup threshold.

- The alarm function is tripped by the rms value of an earth-leakage current
- This alarm signals an earth-leakage current under the pickup value and does not produce circuit-breaker tripping.

Current-unbalance protection I unbal

■ This protection is activated by an adjustable level of unbalance between the RMS values of the three phase currents.



- From:
- $\hfill \square$ I avg is the average value of the rms currents of the three phases

I avg =
$$\frac{11 + 12 + 13}{3}$$

- □ E max is the maximum difference between the current of each phase and I avg
- Micrologic H uses the two values above to calculate the current unbalance:

Maximum-current protection per phase Imax

- Protection values may be set for each of the following currents:
- □ <u>11</u> max: maximum current on phase 1
- \square $\overline{\underline{\mathsf{I2}}}$ max: maximum current on phase 2
- □ 13 max: maximum current on phase 3
- □ IN max: maximum current in the neutral
- This function calculates the rms demand value of the current for the given phase $(\overline{11}, \overline{12}, \overline{13})$ or the neutral $(\overline{1N})$, over a sliding time interval.

The time interval is the same as that for the calculation of the demand currents in the "Metering" menu.

Settings are made in the "Metering setup" menu.

Note

IN max protection does not take into account the neutral-protection setting (N, N/2, 1.6 x N, OFF).

Voltage protection


Minimum voltage, maximum voltage, voltage unbalance


For the pickup and dropout thresholds and time delays, see the technical appendix.

Operating principle

protection tripped by a minimum value

protection tripped by a maximum value





- 1: pickup threshold
- 2: pickup time delay
- 3: dropout threshold
- 4: dropout time delay
- For protection tripped by a minimum or maximum value, it is possible to set:
- □ a pickup threshold (1) that activates an alarm, a contact and/or tripping
- $\ \square$ a pickup time delay (2) that steps in when the pickup threshold (1) is reached
- $\hfill \square$ a dropout threshold (3) corresponding to deactivation of the alarm and/or contact
- $\hfill \square$ a dropout time delay (4) that steps in when the dropout threshold (3) is reached
- For protection tripped by a minimum value, the dropout threshold is always greater than or equal to the pickup threshold
- For protection tripped by a maximum value, the dropout threshold is always less than or equal to the pickup threshold
- If both the minimum and maximum protection functions are activated at the same time, the minimum threshold is automatically limited to the value of the maximum and vice versa.

If the voltage protection functions are activated and the voltage measurement inputs are still energised, it is impossible to reset and close the circuit breaker.

Minimum-voltage protection U min

- This function calculates the minimum rms value of the three phase-to-phase voltages
- Protection is activated when at least one of the three phase-to-phase voltages (U12, U23, U31) is below the threshold set by the user
- This protection function does not detect phase failure.


Maximum-voltage protection U max

- This function calculates the maximum rms value of the three phase-to-phase voltages
- Protection is activated when the three phase-to-phase voltages (U12, U23, U31) are simultaneously above the threshold set by the user.

Voltage-unbalance protection U unbal

This protection is activated by an adjustable level of unbalance between the rms values of the three phase-to-phase voltages.

This function calculates the rms value of the unbalance between the three phase-to-phase voltages.



- From:
- $\hfill \square$ U avg is the average value of the rms voltages of the three phases

U avg =
$$\frac{U12 + U23 + U31}{3}$$

- □ E max: is the maximum difference between the voltage of each phase and U avg
- Micrologic H uses the two values above to calculate the voltage unbalance:


Other protection


Reverse power, min. frequency, max. frequency, phase rotation

For the pickup and dropout thresholds and time delays, see the technical appendix.

Operating principle

protection tripped by a minimum value protection tripped by a maximum value





- 1: pickup threshold
- 2: pickup time delay
- 3: dropout threshold
- 4: dropout time delay
- For protection tripped by a minimum or maximum value, it is possible to set:
- □ a pickup threshold (1) that activates an alarm, a contact and/or tripping
- $\ \square$ a pickup time delay (2) that steps in when the pickup threshold (1) is reached
- □ a dropout threshold (3) corresponding to deactivation of the alarm and/or contact
- □ a dropout time delay (4) that steps in when the dropout threshold (3) is reached
 For protection tripped by a minimum value, the dropout threshold is always great
- For protection tripped by a minimum value, the dropout threshold is always greater than or equal to the pickup threshold
- For protection tripped by a maximum value, the dropout threshold is always less than or equal to the pickup threshold
- If both the minimum and maximum protection functions are activated at the same time, the minimum threshold is automatically limited to the value of the maximum and vice versa.

Reverse-power protection rP max

- This function calculates the value of the total active power on the three phases
- The function is activated when the total active power of the three phases flows in the direction opposite that set by the user is greater than the pickup threshold (1) for a time greater than the time delay (2).

Note:

the direction of flow is set by the user in the "Power sign" section of the "Micrologic setup" menu under "History, maintenance and settings".

- + corresponds to the normal direction of flow, i.e. from the top terminals on the circuit breaker to the bottom terminals
- is the opposite.

If the voltage protection functions are activated and the voltage measurement inputs are still energised, it is impossible to reset and close the circuit breaker.

Minimum and maximum-frequency protection F min. and F max

These functions monitor the value of the frequency on the distribution system.

Phase-rotation alarm

This alarm is activated if two of the three phases are inverted.

Note:

the alarm is activated following a fixed 300-millisecond time delay. If one of the phases is absent, the alarm will not operate. If the 400 Hz frequency is set, the alarm cannot be activated.

Load shedding and reconnection

For the pickup and dropout thresholds and time delays, see the technical appendix.


Load shedding and reconnection depending on current

The pickup curve for load shedding and reconnection depending on current is parallel to the LT I²t and Idmtl curves. If a "without long-time protection" rating plug is installed, the load shedding/reconnection function based on current cannot be activated.

- \blacksquare I²t protection: the neutral is taken into account
- Idmtl: the neutral is not taken into account.

This function does not trip the circuit breaker, but can be used to set off an alarm linked to an M2C or M6C contact (disconnection and reconnection of non-priority loads).

The load-shedding and reconnection function is determined by thresholds and time delays.




- 1: pickup threshold
- 2: pickup time delay
- 3: dropout threshold
- 4: dropout time delay

The pickup threshold is always greater than or equal to the dropout threshold.

Load shedding and reconnection depending on power

Load shedding and reconnection depending on power calculates the total active power on the three phases. This function does not trip the circuit breaker, but can be used to set off an alarm linked to an M2C or M6C contact (disconnection and reconnection of non-priority loads).

The load-shedding and reconnection function is determined by thresholds and time delays.



- 1: pickup threshold
- 2: pickup time delay
- 3: dropout threshold
- 4: dropout time delay

The pickup threshold is always greater than or equal to the dropout threshold.

Measurements

Current and voltage

For the setting ranges and measurement accuracies, see the technical appendix.

Instantaneous current

Micrologic H control units offer two, non-exclusive measurement possibilities.

■ On the bargraph display on the main screen

The instantaneous current of the most heavily loaded phase is automatically displayed in amperes for phases 1, 2, 3 and the neutral (depending on the neutral protection settings). The bargraph indicates the percent load of the three phases.

■ In the I inst. section of the instantaneous currents

 \square display in amperes of the instantaneous currents I (rms) on phases I1, I2 and I3 and the neutral current IN, the ground-fault current Ig (Micrologic 6.0 H), the earth-leakage current I \triangle n (Micrologic 7.0 H)

☐ the maximum instantaneous currents are displayed and stored in memory

☐ the stored maximums can be reset at any time.

Demand current

■ Display of the demand current on phases $\overline{11}$, $\overline{12}$, $\overline{13}$ and the neutral $\overline{1N}$ (depending on the type of distribution system)

■ Selection of the demand calculation method

■ Display of the interval over which the value is calculated

■ The maximum demand values are displayed and stored in memory

■ The stored maximums can be reset at any time.

Note:

the calculation method, the type of calculation window (fixed or sliding) and its duration may be set in the "Metering setup" menu under "History, maintenance and setup".

Phase-to-neutral and phase-to-phase voltages

Micrologic H offers different voltage measurements

■ phase-to-phase voltages (rms) between phases U12, U23 and U31, displayed in volts

■ phase-to-neutral voltages (rms) between the phases and the neutral V1N, V2N and V3N, displayed in volts.

Average voltage

Average Uavg of the instantaneous voltages between phases U12, U23 and U31.


Phase rotation

Displays the phase sequence.

Voltage unbalance

Display of the unbalance Uunbal between the three phase-to-phase voltages, displayed as a percentage.

To display the phase-to-neutral voltages, select the "3Φ 4w 4CT" option in "System type" in the "Metering setup" menu under "History, maintenance and setup".



■ From:

 $\hfill \square$ U avg is the average value of the rms voltages of the three phases

U avg =
$$\frac{U12 + U23 + U31}{3}$$

□ E max is the maximum difference between the voltage of each phase and U avg

■ Micrologic H uses the two values above to calculate the voltage unbalance

Measurements

Power, energy and frequency

For the setting ranges and measurement accuracies, see the technical appendix.

Instantaneous power and power factor

Micrologic H offers a number of different measurements.

- Total power measurements:
- □ instantaneous active power P in kW
- □ instantaneous reactive power Q in kvar
- □ instantaneous apparent power S in kVA
- Measurement of the power factor PF.

Demand power

- Display of the demand values for the active power P, reactive power Q and apparent power S
- Selection of the demand calculation method
- Display of the interval over which the value is calculated
- The maximum demand values are displayed and stored in memory
- The stored maximums can be reset at at any time.

Note:

- the calculation method, the type of calculation window (fixed or sliding) and its duration may be set in the "Metering setup" menu under "History, maintenance and setup".
 the synchronisation function (Synchro.Com) is available only with the COM communication
- option; with this function, the demand power is determined on the basis of a signal synchronised by the communication module.
- these settings apply to all demand powers (active power P, reactive power Q and apparent power S). If the settings are modified, the demand values are systematically recalculated.

Energy

Micrologic H offers a number of different measurements:

- total energy:
- $\hfill\Box$ total active energy E.P in kWh
- □ total reactive energy E.Q in kvarh
- □ total apparent energy E.S in kVAh
- energy consumed (Energy in), positively incremented:
- □ active energy E.P in kWh
- □ reactive energy E.Q in kvarh
- energy supplied (Energy out), negatively incremented:
- □ active energy E.P in kWh
- □ reactive energy E.Q in kvarh
- energy values can be reset.

- the Energy in and Energy out values are incremented according to the power sign set in the "Metering setup" menu under "History, maintenance and setup".
 as standard, the total calculated energy values are "absolute total values".

They represent the sum of the energy in and out values:

- \Box EP = Σ EP in + Σ EP out
- \Box EQ = Σ EQ in + Σ EQ out
- as an option (access exclusively via the COM communications option), energy can be
- calculated algebraically: \Box EP = Σ EP in Σ EP out
- \square EQ = Σ EQ in Σ EQ out

These values are called "signed" energies.

Frequency

The frequency of the distribution system is displayed in Hz.

Harmonic measurements

Origin and effects

Harmonics represent the most common power problem encountered in today's electrical installations.

When harmonics are present, the current or voltage waveform is distorted, i.e. it is no longer perfectly sinusoidal.

A distorted current or voltage waveform disturbs the distribution of electrical power and power quality is not optimum.

Definition of harmonics

A periodic signal is a combination of:

☐ the original sinusoidal signal at the fundamental frequency

□ other sinusoidal signals (the harmonics) with frequencies that are whole-number multiples of the fundamental frequency

☐ a DC component, where applicable.

Any periodic signal can therefore be represented as the sum of a number of terms:

$$y(t) = Y_0 + \sum_{n=1}^{\infty} Y_n \sqrt{2} \sin(n\omega t - \phi_n)$$

where

- Yo is the value of the DC component (generally equal to zero and considered as such hereinafter)
- Yn is the rms value of the nth harmonic
- lacksquare ω is the angular frequency of the fundamental
- \blacksquare φ n is the phase displacement of the harmonic component at t = 0.


A **harmonic of order n**, referred to as the nth harmonic, is the sinusoidal component of a signal with a frequency that is n times higher than the fundamental frequency.

For example, the current and voltage waveforms distributed on the European electrical power grid have the following characteristics:

- the fundamental frequency is 50 hertz (Hz)
- the 2nd harmonic has a frequency of 100 Hz
- the 3rd harmonic has a frequency of 150 Hz
- the 4th harmonic has a frequency of 200 Hz
- **.**..


A distorted waveform is the result of superimposing the various harmonics on the fundamental.

The figure opposite shows a current distorted by harmonics.



Harmonic measurements

Origin and effects



Origin of harmonics

Harmonics are caused by non-linear loads.

A load is said to be **non-linear** when the current that it draws does not have the same waveform as the voltage. Typical examples of non-linear loads are those using **power electronics**. Such loads are increasingly numerous and their share in overall electrical consumption is growing.

Examples are:

- industrial equipment including welding machines, arc furnaces, induction furnaces, rectifiers, etc.
- variable speed drives for asynchronous or DC motors
- office equipment including computers, photocopy machines, fax machines, etc.
- household equipment including televisions, microwave ovens, neon lighting, UPSs, etc.

Non-linear phenomena may also be caused by the saturation of transformers and other equipment.

Effects of harmonics

The flow of harmonics in distribution systems can cause serious problems:

- increased currents flowing in the system and overloads
- additional losses and premature ageing of equipment
- disturbances to loads due to voltage harmonics
- disturbances in communication networks.

The above effects can also have major financial impact due to:

- the cost of equipment (premature replacement, oversizing)
- increased power losses and the need to subscribe to higher power levels
- losses in productivity (unnecessary tripping of protection devices).

Origin and effects

What is an acceptable level of harmonics?

The presence of harmonics in a distribution system should be assessed:

- as a preventive measure, to gain information on the system and detect any drift
- as a corrective measure, to diagnose a disturbance or check the effectiveness of a solution.

Harmonic disturbances are subject to a number of standards and regulations:

- compatibility standards designed for public utilities:
- □ low voltage: IEC 61000-2-2
- □ medium voltage: IEC 61000-2-4
- electromagnetic compatibility (EMC) standards:
- $\hfill\Box$ for loads drawing less than 16 A: IEC 61000-3-2 $\hfill\Box$ for loads drawing more than 16 A: IEC 61000-3-4
- utility recommendations for installations.

A number of international studies have produced data used to estimate the typical harmonic values encountered in utility distribution systems. Below is a table presenting the levels of harmonics that, in the opinion of many utility companies, should not be exceeded.

Voltage individual harmonics of even and odd orders for:

- low-voltage (LV) systems
- medium-voltage (MV) systems
- extra high voltage (EHV) systems.

Odd harmonics (not multiples of 3)			Odd har	rmonics (multiples	s of 3)	Even harmonics				
Order n	LV	MV	EHV	Order n	LV	MV	EHV	Order n	LV	MV	EHV
5	6	6	2	3	5	2.5	1.5	2	2	1.5	1.5
7	5	5	2	9	1.5	1.5	1	4	1	1	1
11	3.5	3.5	1.5	15	0.3	0.3	0,3	6	0.5	0.5	0.5
13	3	3	1.5	21	0.2	0.2	0.2	8	0.5	0.2	0.2
17	2	2	1	>21	0.2	0.2	0.2	10	0.5	0.2	0.2
19	1,5	1.5	1						12	0.2	0.2
23	1.5	1	0.7						>12	0.2	0.2
25	1.5	1	0.7								

Note:

the individual harmonic content of a harmonic of order n is defined as the percentage of its rms value with respect to the rms value of the fundamental. This value is displayed on the graphic screen of the Micrologic H.

Which harmonics are we concerned with?

- Individual harmonics of odd orders at low frequency
- Mainly order 3, 5, 7, 11 and 13.

Quality indicators

Micrologic H control units can quantify and evaluate the harmonic distortion of current and voltage waves using the quality indicators listed below:

- measurement of the fundamental signal
- phase displacement of the fundamental signals
- harmonic distortion THD and thd
- cos φ
- power factor
- K factor
- distortion power
- distortion factor
- crest factor
- amplitude spectrum of even and odd harmonics up to order 31
- displacement spectrum with respect to V1N of even and odd harmonics up to order 31.

These indicators are the indispensable tools used to determine any required corrective action.

Access to quality indicators

The quality indicators may be accessed on the Micrologic H screen and/or via the communication module.

Quality indicator	On the Micrologic H screen	Via the communication module
Measurement of		
the fundamental		
Phase displacement of		
the fundamental	-	•
Harmonic distortion		
THD and thd		
Cos φ	-	•
Power factor	•	•
K factor	-	•
Distortion power	-	
Distortion factor	-	•
Crest factor	-	
Amplitude spectrum of odd harmonics up to order 31		
Amplitude spectrum of		
even harmonics up to order 31		•
Displacement spectrum ith respect to V1N of		
even and odd harmonics		
up to order 31	-	•

Quality indicators

Fundamental

Micrologic H control units can determine the value of the fundamental signals for:

- currents: I1, I2, I3 and IN (in amperes)
- voltages
- □ phase-to-neutral V1N, V2N, V3N (in volts)
- □ phase-to-phase U12, U23, U31 (in volts)
- power:
- □ active P (kW)
- □ reactive Q (kVAR)
- □ apparent S (kVA).

Current and voltage rms values

■ The rms current is the square root of the sum of the squares of the rms voltage values for each harmonic from the fundamental to an infinite order.

Irms =
$$\sqrt{\sum_{n=1}^{\infty} \prod_{r=1}^{2}}$$

■ The rms voltage is the square root of the sum of the squares of the rms current values for each harmonic from the fundamental to an infinite order.

Urms =
$$\sqrt{\sum_{n=1}^{\infty} U_n^2}$$

Total harmonic distortion of current THD(I)

The total harmonic distortion of current is the ratio of the square root of the sum of the squares of the harmonic currents from the 2nd to an infinite order to the **fundamental** current.

$$THD(I) = \frac{\sqrt{\sum_{n=2}^{\infty} \frac{2}{n}}}{\frac{|f_{und}|}{|f_{und}|}} THD(I) = \sqrt{\frac{\frac{|I_{ms}|}{|f_{und}|}}{1}} - 1$$

Note:

- Ifund is the fundamental current.
- Irms is the rms current.

Distortion is expressed as a percentage and may exceed 100%.

Defined by standard IEC 61000-2-2, total harmonic distortion THD(I) is a single value that expresses the distortion of the current flowing at a given point in a distribution system.

- Micrologic H control units measure the THD for currents I1, I2, I3 and IN (in amperes), taking into account harmonic orders up to 31.
- The total harmonic distortion of current characterises the distortion of the current waveform.
- Loads causing distortion are identified by measuring the THD(I) on the incoming and outgoing circuits.
- THD(I) values measured and the corresponding phenomena in an installation.
- $\hfill \Box$ THD(I) under 10% is considered normal. There is no particular risk of malfunctions.
- □ THD(I) between 10 and 50% signals a significant level of harmonic disturbance. There is a risk of temperature rise, which means that cables and sources must be oversized.
- $\hfill \Box$ THD(I) greater than 50% signals major harmonic distortion. Malfunctions are probable. An in-depth analysis and the installation of compensation equipment is required.

Quality indicators

Total harmonic distortion of voltage THD(U)

The total harmonic distortion of voltage is the ratio of the square root of the sum of the squares of the harmonic voltages from the 2nd to an infinite order to the **fundamental** voltage.

THD(U) =
$$\frac{\sqrt{\sum_{n=2}^{\infty} U_{n}^{2}}}{U_{\text{fund}}}$$

Note:

Ufund is the fundamental voltage.

Distortion is expressed as a percentage and may exceed 100 %.

Defined by standard IEC 61000-2-2, total harmonic distortion THD(U) is a single value that expresses the distortion of the voltage at a given point in a distribution system.

- Micrologic H control units measure the THD for:
- □ phase-to-neutral voltages V1N, V2N, V3N (in volts)
- □ phase-to-phase voltages U12, U23, U31 (in volts) taking into account harmonic orders up to 31.
- Total harmonic distortion of voltage characterises the distortion of the voltage waveform.
- THD(U) values measured and the corresponding phenomena in an installation:
- $\hfill\Box$ THD(U) under 5 % is considered normal.

There is no particular risk of malfunctions.

- $\hfill \Box$ THD(U) between 5 and 8 % signals a significant level of harmonic disturbance. Malfunctions may occur.
- $\hfill \Box$ THD(U) greater than 8 % signals major harmonic distortion. Malfunctions are probable. An in-depth analysis and the installation of compensation equipment is required.

Quality indicators

Total harmonic distortion of current thd(I)

The total harmonic distortion of current is the ratio of the square root of the sum of the squares of the harmonic currents from the 2nd to an infinite order to the **rms** current.

thd(I) =
$$\frac{\sqrt{\sum_{n=2}^{\infty} \prod_{n=2}^{\infty} n}}{\text{Irms}}$$

Note:

Irms is the rms current.

■ Micrologic H control units measure the thd(I) for currents I1, I2, I3 and IN, taking into account harmonic orders up to 31.

Defined by standard IEC 61000-2-2, total harmonic distortion thd(I) is a single value that expresses the distortion of the current flowing at a given point in a distribution system.

Total harmonic distortion of voltage thd(U)

The total harmonic distortion of voltage is the ratio of the square root of the sum of the squares of the harmonic voltages from the 2nd to an infinite order to the **rms** voltage.

thd(U) =
$$\frac{\sqrt{\sum_{n=2}^{\infty} U^{2}}}{Urms}$$

Note:

Urms is the rms voltage.

- Micrologic H control units measure the thd(U) for:
- □ phase-to-neutral voltages V1N, V2N, V3N (in volts)
- $\hfill \Box$ phase-to-phase voltages U12, U23, U31 (in volts) taking into account harmonic orders up to H31.

Quality indicators

Cos o

 $\cos \phi$ is the ratio between the active power Pfund and the apparent power Sfund of the fundamental (1).

$$\cos \varphi = \frac{Pfund}{Sfund}$$

Note:

- Pfund is the active power of the fundamental.
- Sfund is the apparent power of the fundamental.

Cos ϕ pertains exclusively to the fundamental frequency. Consequently, if there are harmonics, the value of the cos ϕ is not the same as that of the power factor.

Power factor PF

The power factor is the ratio between the active power P and the apparent power S.


$$PF = \frac{P}{S}$$

Note:

- P is the active power.
- S is the apparent power.
- the power factor must not be confused with the $\cos \varphi$. The power factor is equal to the $\cos \varphi$ only when the signal is perfectly sinusoidal (no harmonics).
- If the measured power factor is not equal to the $\cos \varphi$ (the power factor is lower), that may be an initial indication of harmonic disturbances in an installation.
- The power factor PF is the means to evaluate the oversizing required for the power sources in an installation.
- There is a relation between the power factor and the total harmonic distortion of current THD(I). When the voltage signal is (virtually) sinusoidal, the power factor may be roughly calculated using the equation below:

$$PF \approx \frac{\cos \varphi}{\sqrt{1 + \left(THD(I)\right)^2}}$$

When plotted, the above equation produces the graph below showing the PF to $\cos \phi$ ratio, depending on the THD(I)



Quality indicators

K factor

The K factor is a quality indicator that indicates high-order harmonics.

K factor =
$$\frac{\sqrt{\sum_{n=2}^{\infty} n^2 l_n^2}}{Irms}$$

Note:

I is the amplitude of the current.

The K factor is used to:

- calculate temperature rise in the busbars
- size the transformers for non-linear loads.

Distortion power

When there are harmonics, the relation $S^2 = P^2 + Q^2$ is no longer valid. The distortion power D is defined by the equation below:

$$D = \sqrt{S^2 - P^2 - Q^2}$$

Distortion factor

The distortion factor is the relation between the power factor and the $\cos \varphi$.

Crest factor

The crest factor is the relation between the peak value of the current or voltage and the corresponding rms value.

Crest factor =
$$\frac{I_{peak}}{I_{rms}}$$
 or crest factor = $\frac{U_{peak}}{U_{rms}}$

Note:

- Irms is the rms current.
- Urms is the rms voltage.
- Possible values:
- \Box for a sinusoidal signal, the crest factor is equal to $\sqrt{2}$
- $\ \square$ for a non-sinusoidal signal, the crest factor may be less than or greater than $\sqrt{2}$.
- The crest factor is used to characterise the capacity of a source (UPS or generator) to supply high instantaneous currents. In particular, it draws attention to the presence of exceptional peak values with respect to the rms value. Computer equipment, for example, draws highly distorted current with a crest factor that can reach 3 or even 5.
- Typical crest factors for the currents drawn by non-linear loads are much higher than $\sqrt{2}$. They are often equal to 1.5 or 2 and can reach 5 in critical cases.
- A very high crest factor means that there can be high temporary overcurrents, which, when detected by the protective devices, may result in nuisance tripping.

Quality indicators

The communication module can be used to determine for each harmonic order up to 31:

- the amplitude spectrum
- the displacement spectrum with respect to the phaseto-neutral voltage V1N.

FFT amplitude spectrum of odd harmonic orders from 3 up to 31


Each type of distorting device has its own harmonic-current "fingerprint", with different amplitudes and displacements.

These values, in particular the amplitude for each harmonic order, are essential for the analysis of power quality.

■ FFT (Fast Fourier Transform) frequency spectrum

The Micrologic H control unit can display the FFT amplitude spectrum of odd harmonics from the 3rd up to 31st.

The Micrologic H control unit presents the amplitude of each harmonic order with respect to its frequency in the form of a histogram, called a spectral analysis.



Above is an example of the spectral analysis of a square-wave signal.

■ Harmonic content of the nth harmonic for the phases I1, I2, I3

The individual harmonic content of a harmonic of order n is defined as the percentage of its rms value with respect to the rms value of the fundamental:

in (%) = 100
$$\frac{In}{Ifund}$$
 or $un (%) = 100 \frac{Un}{Ufund}$

- Note:

 I fund is the fundamental current.

 U fund is the fundamental voltage
- Harmonic content of the nth harmonic for neutral current.

The individual harmonic content of a harmonic of order n is defined as the percentage of its rms value with respect to the rms value of the Neutral:

in (%) = 100
$$\frac{In}{IN \text{ rms}}$$
 or un (%) = 100 $\frac{Un}{UN \text{ rms}}$

- IN rms is the Neutral rms current.
- UN rms is the Neutral rms voltage.
- The Micrologic H control unit indicates the FFT amplitude spectrum and the individual distortion level for harmonic orders from 3 to 31 for:
- □ each current I1, I2, I3 and IN
- □ each phase-to-phase voltage U12, U23 and U31.
- The Micrologic H control unit also indicates for each current or voltage the corresponding level of total harmonic distortion THD (thd for Neutral current).

Overview of functions

Harmonic measurements Waveform and waveform capture

The communication module may be used to:

- set up "Measurement" or "Protection" alarms
- capture and analyse waveforms; capture may be tripped by the alarms
- captured waveforms are recorded over 4 cycles (resolution of 64 points per cycle).

Micrologic H control units can capture and store current and voltage waveforms using digital sampling techniques similar to those used in oscilloscopes.

Waveform capture is the means to detect weak points in the system and the equipment. Using the information available in the captured waveform, it is possible to determine the level of harmonics as well as the direction and amplitude of the flow of harmonic power.

- Users of Micrologic H control units can record manually via the keypad the following waveforms:
- □ the four currents I1, I2, I3 and IN
- $\hfill\Box$ the three phase-to-neutral voltages V1N, V2N and V3N.
- Waveforms may be displayed on the graphic screen of Micrologic H control units. The recording takes place over one cycle with a measurement range of 0 to 1.5 In for current and 0 to 690 volts for voltage. The resolution is 64 points per cycle.

Schneider

Alarms

For information on the communications option and the portable test kit, see the respective user guides.


- An alarm may be viewed using:
- □ the "Alarm history" menu
- ☐ the COM communications option
- □ the portable test kit.
- The commands in the "Protection" menu are used to attribute a specific operating mode to each of the protection functions:
- □ OFF: protection disabled
- $\hfill \square$ Alarm: the function issues an alarm, but does not trip the circuit breaker
- ☐ Trip + Alarm: the function issues an alarm and trips the circuit breaker.
- The protection functions against overloads (long time), short circuits (short time and instantaneous) and ground faults (ground-fault and earth-leakage currents) automatically result in tripping and cannot be deactivated (Trip mode only).
- \blacksquare The "I $\frac{1}{\pm}$ Alarm" and phase rotation alarms can be set exclusively to OFF or Alarm mode
- The other protection functions for current, voltage, power and frequency may be set to any of the three modes, OFF, Alarm or Trip + Alarm.
- The load shedding and reconnection function may be set to ON or OFF.
- The resettable alarms linked to device tripping are activated when the Ir, Isd/li or I $\frac{1}{2}$ thresholds are overrun.

The Ir alarm is reset one second after tripping. The Isd/Ii and $\frac{1}{2}$ alarms are reset by pressing the \bigcirc button.

Current protection	Off	Alarm	Trip + Alarm	
Ir			•	
Isd / li				
I ‡			•	

■ Delayed alarms are activated when the pickup and dropout thresholds are overrun and the corresponding time delays have expired.

Current protection	Off	Alarm	Trip + Alarm
I ↓ Alarm	-	•	
l unbal	-		•
11 max	•		•
12 max	-		•
13 max	•	•	•
ĪN max		•	•
Voltage protection	Off	Alarm	Trip + Alarm
U min	•	•	•
U max	•		•
U unbal	•		•
Other protection	Off	Alarm	Trip + Alarm
rP max	-	•	•
F min	•		•
F max	•		•
Phase rotation	•		
Shedding/reconnection	Off	On	
Current I	-		
Power P	_		



1000	dentical pickup	and	dropout the	resholds	
DB120	Pickup /	T1		T2	
	Dropout				
	Ir, Isd, Ii, I∔aları	ns			
	Other alarms				

- History logging
- □ Alarm mode: as soon as a given protection threshold is overrun, an alarm is recorded in the "Alarm history"
- □ Trip mode: as soon as a given protection threshold is overrun, the circuit breaker trips and the fault is recorded in the "Trip history".
- The "Protection setup" menu under "History, maintenance and setup" is used to enable or disable the Trip mode that is displayed in the protection-setting screens. On leaving the factory, the protection functions are set to Alarm mode.
- The "M2C / M6C contacts" menu under "History, maintenance and setup" is used to link an M2C or M6C contact to an alarm. M2C and M6C contacts may not be used together. They require a 24 V external power supply.
- The COM communications module can be used to transmit alarms to a supervisor.

Optional M2C and M6C contacts

Other protection:

□ phase rotation.

□ F min

□ F max


□ rP max

An alarm is issued if the Alarm or the Trip + Alarm mode was set for the given protection function.


Caution!

The M2C and M6C contacts require an auxiliary power supply. See the "Power supply" section in the technical appendix.

Wiring diagram for M2C contacts.



Wiring diagram for M6C contacts



- Available types of contacts:
- ☐ M2C: up to two contacts maximum, S1 and S2
- ☐ M6C: up to six contacts maximum, S1 to S6.
- Current protection: □ Ir
- Voltage protection:
- □ U max
- □ U max □ U unbal.
- □ I ≟ Alarm


□ Isd

□ li


- _ I = Alain
- □ I unbal
- □ Ī1 max
- □ Ī2 max
- □ Ī3 max
- □ IN max.
- Load shedding and reconnection:
- □ current I
- □ power P.
- Latching settings:

 $\hfill \square$ non-latching contact: the contact remains activated as long as the fault that caused the alarm has not been cleared


- □ latching contact: the contact remains activated until it is reset ("Reset menu")
- □ time-delay contact: the contact remains activated for the duration of an adjustable time delay or until it is reset ("Reset menu").
- □ locked to 1: the contact is forced to 1 for an automation test
- □ locked to 0: the contact is forced to 0 for an automation test.
- Contact operating diagram for long-time protection



■ Contact operating diagram for short-time, instantaneous and ground-fault protection



■ Contact operating diagram for the other protection functions



Event histories

The interrupted currents are indicated in terms of their peak values.

Trip history

- The trip history is the means to display at any time the parameters measured during the last ten trips.
- For each trip, the following parameters are recorded:
- □ tripping cause
- □ trip threshold
- $\ \square$ interrupted currents in amperes (only if an external power supply is present) for Ir, Isd/Ii, Ig or I \triangle n trips
- □ date
- □ time (hours, minutes and seconds).

Alarm history

- The alarm history is the means to display at any time the parameters measured during the last ten alarms.
- For each alarm, the following parameters are recorded:
- □ alarm cause
- □ alarm threshold
- □ date
- ☐ time (hours, minutes and seconds).

Operation counter

This function is available only via the COM communications option.

■ Micrologic H:

 $\hfill \square$ stores and displays the total number of operations (incremented each time the circuit breaker opens) since the initial installation of the circuit breaker

□ stores and displays the total number of operations since the last reset.

Contact wear indication

This function can be used to:

- Determine the condition of the most worn contact in the circuit breaker. A counter is displayed on the screen. The contacts must be inspected each time the counter reaches a hundred mark. The message "Not available or circuit breaker type not defined" is displayed if the type of circuit breaker has not been defined. In this case, see "Breaker selection" in the "Micrologic setup" menu under "History, maintenance and setup".
- Reset the indicator after changing the main contacts. Reset is also carried out via "Breaker selection" in the "Micrologic setup" menu.


Note:

if the control unit is changed, the circuit breaker must be defined again. In this case, see "Breaker selection" in the "Micrologic setup" menu under "History, maintenance and setup".

LEDs and display screens

LED indicator

Overload bargraph on the main screen





Signals overrun of the long-time current setting (1.125 x lr).

Signals the load level on each phase as a percentage of Ir.

The procedure required to reclose the circuit-breaker following a fault trip is presented in the circuit-breaker user guide.

Concerning the presence or absence of an external power supply, see the "Power supply" section in the technical appendix.

Caution!

The battery maintains the trip indications. If no indications are displayed, check the battery.

Fault-trip indications

■ Control-unit status

The circuit breaker has tripped.

The control unit may or may not have an external power supply.

The voltage measurement inputs may be connected upstream or downstream.

□ control unit without an external power supply and with voltage measurement input connected downstream □ control unit with an external power supply and with voltage measurement input connected upstream



A LED signals the type of fault (Ir, Isd, Ii, Ig, $I\Delta n$ or Ap).



The type of fault is signalled by a LED and on the graphic display.

LEDs and display screens

- Fault-trip LEDs
- The LEDs indicate the type of fault that tripped the circuit breaker
- The LEDs are located in the upper part of the front panel (red Ir, Isd, Ii, Ig, I²n and Ap LEDs)
- When activated, a LED remains ON until it is locally reset.

■ Ir LED



Signals tripping following overrun of the long-time current setting Ir.

■ Isd, li LED



Signals tripping following overrun of the short-time pickup lsd or the instantaneous pickup li.

The self-protection function (excessive temperature, fault detected in ASIC power supply or instantaneous self-protection built into the device) trips the circuit breaker and turns the Ap LED on.

A number of simultaneous causes may result in tripping. For example, a short-circuit and a distribution-system voltage under a set value.

The LED signalling the last fault chronologically is the only one to remain ON. E.g., the Ap LED may signal a voltage drop under a set value where the voltage drop was caused by a short-circuit.

■ Ig, I∆n LED



Signals tripping following overrun of the groundfault pickup Ig or the earth-leakage pickup I∆n.

■ Ap LED



Signals tripping due to:


- self-protection function:
- □ temperature
- □ ASIC power supply
- $\hfill \square$ instantaneous pickup for circuit-breaker self protection
- protection functions:
- □ current unbalance I unbal
- \square maximum current $\overline{11}$ max, $\overline{12}$ max, $\overline{13}$ max, $\overline{1N}$ max;
- □ voltage unbalance U unbal
- □ maximum voltage U max
- □ minimum voltage U min
- □ reverse power rP max
- □ maximum frequency F max
- □ minimum frequency F min.
- LEDs on buttons to access the menus

The activated LED indicates the menu for which the screen is displayed:

- □ "Metering"
- □ "History, maintenance and setup"
- □ "Protection".



COM communications option



Communication optionsDigipact and ModBus are the indispensable elements when integrating Micrologic H in the Digivision and SMS Powerlogic installation-management systems which communicate via the BatiBus and ModBus protocols.

External gateways are available for communication over other networks, including ProfiBus, Ethernet, etc.

The communications option makes possible the following remote functions:

- device identification:
- □ address
- □ device type
- □ control-unit type
- □ type of long-time rating plug
- settings:
- □ reading of the dial settings
- ☐ fine adjustments within the range determined by the dial
- protection and alarm settings
- □ setup of the M2C / M6C contacts.

Operating and maintenance aids Protection and alarm values:

- □ standard
- □ set.
- Measurement values:
- □ currents
- □ voltages, frequencies, power, etc.
- Fault values:
- □ fault type
- □ interrupted current.
- Histories and logs:
- □ trip history
- □ alarm history
- □ event history.
- Indicators:
- □ contact wear, counters, etc.
- □ maintenance register.

Setting up the optional M2C / M6C contacts


Select the command



Select an alarm

Note:

an alarm may be selected if the "Alarm" or "Trip + Alarm" mode was selected during setup of the given protection function, in the "Protection" menu.




Select the command




Set up each contact

■ Select the latching mode



time-delaylocked to 1locked to 0.


Setting up the optional M2C / M6C contacts



Select the command



Reset the contacts to 0



Select the command

Micrologic setup

Language

Setting up the Micrologic control unit

Prior to setting up the protection functions or carrying out measurements, the following operations are required:

- selection of the display language
- entry of the date and time
- entry of the circuit-breaker type
- entry the power sign
- selection of the transformation ratio between the primary and secondary windings if an auxiliary voltage transformer is installed
- entry of the rated frequency.

Select the display language



To return to English

1. Return to the main screen by pressing any of the three buttons





or press the button



followed by any of the three buttons





2. Select the "History, maintenance and setup" menu by pressing




3. Select the "Micrologic setup" menu by moving the cursor up on the first menu. Move the cursor down on the third menu and confirm by pressing

4. Select the "Language" menu by moving the cursor up on the first menu.

Confirm by pressing




Select the command



If the time is set via a communications module, any previous manual setting is automatically erased.

Set the date and time

■ Enter the date and time for time-stamping purposes in the trip and alarm histories.




■ The resolution of the time setting is 20 ms.


Setting up the Micrologic control unit

Date and time are backed up by battery.

If time is not synchronised by the supervisor via the communication module, a drift of up to one hour per year may be observed.



Select the command



The circuit-breaker code is required to identify the device and activate the contact-wear counter.


Note this code if the control unit must be changed (example 03E7).


Enter this code when setting up a new control unit on the circuit breaker.

For a new device, the code is set to zero.

When the main circuit-breaker contacts are replaced, this code must be reset to zero.


Circuit-breaker selection





Setting up the Micrologic control unit


Select the command




By default, Micrologic H uses P+ for the power flowing from top to bottom terminals. The selected direction of flow is valid for:

- measurement of power and the power factor
- measurement of energy
- load shedding and reconnection depending on power.

Select the sign of the power



Select the command




If the supply voltage for the control unit exceeds 690 V, an external voltage transformer must be installed.


To display the true voltage values, enter the transformation ratio between the primary and secondary voltages of the transformer.

Note that if Digipact display modules are used, the rated distribution-system voltage must be entered.

Enter the voltage-transformation ratio




Select the command



If the phase-rotation protection function is activated, the 400 Hz frequency may not be selected. If the 400 Hz frequency is selected, the phase-rotation protection function is disabled.

Enter the rated frequency



Select the command

Metering

System

The neutral current IN cannot be measured with the "3-

phase, 3-wire, 3-CT" and "3-phase, 4-wire, 3-CT" types.

connected to terminal VN of the Micrologic H control unit.

See the "Overview of functions" section for information

on the available types of measurements.

For a 3-pole device, the neutral, if distributed, must be

setup

type

Caution!

Setting up the metering functions

Prior to setting up the protection functions or carrying out measurements, the following operations are required:

- entry of the system type
- selection of the calculation mode for the demand current
- selection of the calculation mode for the demand power
- select the power sign
- select the sign convention for the power factor measurement.

Select the system type

The Micrologic H control unit offers three measurement options:

■ 3 phases, 3 wires, 3 CTs (method using two wattmeters)

The currents on phases I1, I2 and I3 are displayed.

The current on the neutral IN is not displayed.

The phase-to-phase voltages U12, U23 and U31 are displayed.

The phase-to-neutral voltages V1N, V2N and V3N are not displayed.

■ 3 phases, 4 wires, 3 CTs (method using three wattmeters)

The currents on phases I1, I2 and I3 are displayed.

The current on the neutral IN is not displayed.

The phase-to-phase voltages U12, U23 and U31 are displayed.

The phase-to-neutral voltages V1N, V2N and V3N are displayed.

■ 3 phases, 4 wires, 4 CTs (method using three wattmeters)

The currents on phases I1, I2 and I3 are displayed.


The current on the neutral IN is displayed.

The phase-to-phase voltages U12, U23 and U31 are displayed.


The phase-to-neutral voltages V1N, V2N and V3N are displayed.

Note:


it is advised not to use the "3-phase, 4-wire, 4-CT" type of measurement unless the neutral is effectively connected to the control unit (four-pole circuit breaker with an external voltage-measurement input).




Select the command




Thermal method based in I²t calculation.






Select.



Adjust.



Confirm.

Setting up the metering **functions**

Current demand

Calculation method block interval Window type sliding

Interval 15 min

Select.

Current demand

Calculation method block interval Window type sliding

Interval 20 min

₹ 4 Adjust.

Current demand

Calculation method block interval

Window type sliding

Interval 20 min

Confirm.

Select the command



Metering setup

Power demand

The synchronisation function "Synchro.Com" is available only with the COM communication option. With this function, the demand power is determined on the basis of a signal synchronised by the communication module.

Thermal method based on I2t calculation.

Sliding window:

power demand is refreshed every 15 secondes.

power demand is refreshed at the end of the time interval.

Power demand

Calculation method

thermal

Window type sliding

Interval 15 min

Select.

Power demand

Select the calculation method for demand power

Calculation method

block interval

Window type sliding

Interval 15 min

₹ 4

Choose between:

- thermal
- block interval
- sync. to comms

Power demand

Calculation method

> block interval

Window type sliding

Interval 15 min

Confirm.

Power demand

Calculation method block

interval Window type

sliding

Interval 15 min

Select.

Power demand

Calculation method block

interval Window type

fixed

Interval 15 min

₹ 4

Choose between fixed or sliding.

Power demand

Calculation method block interval


Window type

fixed

Interval 15 min

Confirm.

Setting up the metering functions




Select the command




See page 106 for the description of power factor sign conventions.

Set up the power-factor calculation



Setting up the COM communications option

Select the command




As soon as the Digipact or Modbus communications option is connected, the control unit recognises it and displays the type of module on the graphic screen. Automatic time updates are possible only with the Modbus system.

When a COM communications option is used, it is necessary to:

- set up the COM communications option
- authorise remote setting of the Micrologic control unit
- authorise remote control of the circuit breaker.

View and set up the communications option



Adjust all the other parameters for the communications option in the same manner.


	DIGIPACT (read only)	MODBUS (read and set up)
Address	1 - 255	1 - 47
Baud rate		9600 bauds 19200 bauds
Parity		Even

Select the command




The access code is a password that must be provided by the supervisor prior to accessing the Micrologic settings.

Authorise remote setup of Micrologic



Setting up the COM communications option

If the operator does not enter a specific access code, the default access code is 0000 and is requested by the supervisor.




Select the command




It is possible to set circuit-breaker control to local only ("Manual") or to local and remote ("Auto").







Fine adjustment of the long-time I²t, short-time and instantaneous settings using the keypad

Select the command.






When all the settings have been adjusted, quit the screen by pressing one of the menu-access buttons. This saves the new values.




Fine adjustment of the long-time Idmtl, short-time and instantaneous settings using the keypad




Fine adjustment of the groundfault and earth-leakage protection setting using the keypad











When all the settings have been adjusted, quit the screen by pressing one of the menu-access buttons. This saves the new values.



Setting the neutral protection

Select the command




Caution!

Selection of the CT type determines the "Ineutral" protection in the "Protection" menu.


- "none" disables the neutral protection.
- "Internal" for a four-pole circuit breaker provides access to the N/2, N and OFF protection functions.
- "External" for a three-pole circuit breaker provides access to the N/2, N, 1.6 x N and OFF protection functions.

Using the keypad on the control unit



■ internal■ external


Type of circuit breaker	Possibles choices			
Four-pole	OFF: no neutral protection N / 2: half neutral protection N: full neutral protection			
Three-pole	OFF: no neutral protection N / 2: half neutral protection N: full neutral protection 1.6 x N: oversized neutral protection			




Note:

On four-pole circuit breakers, setting of the neutral using the keypad is limited by the dial setting.

Setting the I ≠, I unbal, Imax, U min, U max, U unbal, rP max, F min, F max, and phase-rotation protection functions using the keypad



Setting the I ≠, I unbal, Imax, U min, U max, U unbal, rP max, F min, F max, and phase-rotation protection functions using the keypad




For protection tripped by a maximum value, the dropout threshold is always less than or equal to the pickup threshold.


For protection tripped by a minimum value, the dropout threshold is always greater than or equal to the pickup threshold.

If both the minimum and maximum protection values are activated, the minimum threshold is automatically limited to the value of the maximum and vice versa.

■ Set the pickup and dropout thresholds and time delays





When all the settings have been made, quit the screen by pressing one of the menu-access buttons. This saves the new values.



Setting load shedding / reconnection

Select the command





Setting load shedding / reconnection

Example: Take load shedding / reconnection depending on power. Load Load Load P sheddina shedding shedding Off On On Pick up Pick up Pick up 1000kW 1000kW 1000kW 3600s 3600s 3600s Drop out Drop out Drop out 1000kW 1000kW 1000kW 10s 10s 10s 4 then **(₹)** (**‡**) Select the first setting. Confirm. Select: ■ Off: load shedding disabled ■ On: load shedding enabled. Load Load Load shedding shedding shedding On On On Pick up Pick up Pick up 1000kW 1000kW 1000kW 3600s 3600s 3600s Drop out Drop out Drop out 980kW 985kW 985kW 10s 10s 10s then ₹ 4 4 Select the existing Adjust. Confirm. dropout threshold. When all the settings have been made, quit the screen Load Load shedding shedding On On Pick up Do you want Pick up to save new 1000kW 1000kW settings? 3600s 3600s Drop out Drop out no 985kW 985kW 10s 10s yes then

Quit the setting screen.

Set the other parameters.

Confim.

by pressing one of the menu-access buttons.

This saves the new values.

Current measurements


Only the measurements for the phase (1, 2, 3) and neutral currents are displayed on the main screen.

The neutral current is displayed if the neutral CT is set to internal or external (see "Ineutral (A)" settings in the "Current protection" menu).

Continuous current measurement


The bargraph displays the value in amperes of the most heavily loaded phase.






The and buttons may be used to display the currents on the three phases. If the operator no longer uses the buttons for a few seconds, the bargraph returns to the display of the most heavily loaded phase.

Select the command




Measure an instantaneous-current value

■ Measure the instantaneous currents




■ Check the instantaneous-current maximeter




Select. View.


Current measurements




Select the command



Measure a demand-current value



Current measurements




Voltage measurements

Select the command




The phase-to-neutral voltages are displayed if the selected system type is 3-phase, 4-wire (see page 55).


Measure an instantaneous-voltage value (U or V)



Measure the average voltage U avg




Measure the voltage unbalance U unbal




Voltage measurements

Determine the phase sequence




Power measurements

Select the command




To ensure reliable power and power-factor measurements, the "Power sign" and "Sign convention" parameters must be set.


Measure an instantaneous-power value




Measure the power factor




Select the command





Power measurements



Reset (-/+)

 \overline{s}

₹

cancel the reset.

Reset (-/+)

(kVA) 2700

 $\overline{\mathsf{s}}$

(kVA)


Energy measurements

Select the command



To ensure reliable energy measurements, the "Power sign" and "Sign convention" parameters must be set.

Measure the energy values



Select.

Select the energy value to be measured:

- total energy
- energy in (positive component in the total energy)
- \blacksquare energy out (negative component in the total energy).

E in E out E total E.P (kWh) E.P (kWh) E.P (kWh) 20168 +21320 168 E.Q (kvarh) E.Q (kvarh) E.Q (kvarh) -2733 -277Ó 33 E.S (kVAh) 22926


View the energy

in values.

Reset the energy values

View the total energy

values.




View the energy

out values.


Harmonic measurements

Waveform capture


Select the command




Waveform capture for currents I1, I2 and I3



Waveform capture for neutral current IN




Waveform capture for voltages U12, U23 and U31




Harmonic measurements

Fundamentals

Select the command




Measure the fundamental currents




View.

Measure the fundamental voltages




Measure the fundamental power values




Harmonic measurements THD


Select the command



Measure the total harmonic distortion (THD) of the current (with respect to fundamental)




Measure the total harmonic distortion (THD) of the voltage (with respect to fundamental)




Harmonic measurements thd


Select the command



Measure the total harmonic distortion (thd) of the current (with respect to rms value)



Measure the total harmonic distortion (thd) of the voltage (with respect to rms value)



Harmonic measurements


FFT amplitude spectrum

Select the command




Note: FFT= Fast Fourier Transform

Measure the amplitude spectrum of the current harmonics



Select a current.

View the individual distortion of the 3rd harmonic




... and the other odd harmonics up to the 31st.

Harmonic measurements


FFT amplitude spectrum

Measure the amplitude spectrum of the voltage harmonics



Select a voltage.

View the individual distortion of the 3rd harmonic




Select.

... and the other odd harmonics up to the 31st.

Frequency measurements

Select the command



F (Hz)
60.0

View.

04443728AA - 01/2009 Schneider


83

Resetting fault indications

Caution!

If the circuit breaker remains closed and the Ap LED remains ON after the reset, open the circuit breaker and contact the after-sales support department.

The fault indication is maintained until it is reset on the control panel. Press the reset button.



Viewing the event histories

Select the command



Event history

Trip history

Trip history

Trip history

U min 27/01/1999

Ir

27/06/1998

Ir

18/02/1998

Trip
22/11/1999
02:04:04
Umin 160V

Select a fault.

View.

Select the command



Event history

Alarm history

Alarm history

Alarm history

> I2 max 27/01/1999

In max 23/03/1998

U max 12/02/1998

then Select an alarm.

Alarm 27/01/1999 13:06:09 I2 max 3400A

View.

Operation counter and contact-wear indicator

Select the command



Event history

Operation counter

View and/or reset the operation counter

Number of operations

Total 17824

Operations since last reset

6923

Reset (-/+)

Number of operations

Total 17824

Operations since last reset

0

₹

Reset...

Reset (-/+)

Reset (-/+)

then

or cancel the reset,

then confirm.

Number of

operations

Operations since last

Total

reset

6923

17824

Select the command



Event history

Contact wear

Contact wear is indicated from 0 to 900. The contacts should be inspected every time the counter reaches a multiple of 100.


Check the wear of the contacts

Contact wear


59

Checking/replacing the battery

Check the control-unit battery




Press and hold down the test button on the control unit to check the LEDs and the battery. The battery information is displayed if the control unit is equipped with an external power supply or if the circuit breaker is ON.



If the battery needs to be changed, order a new battery with the Schneider Electric catalogue number 33593.


- Lithium battery
- 1.2 AA, 3.6 V, 800 mA/h
- Ambient temperature: 130°C.

Replacing the control-unit battery



3. insert a new battery. Check the polarity.


4. put the cover back in place. Press the battery-test button to check the new battery.





Test the ground-fault (Micrologic 6.0 H) and earthleakage (Micrologic 7.0 H) protection functions The circuit breaker must be supplied with power and closed for the test.

Press the TEST button. The circuit breaker should trip.




If the circuit breaker does not trip, contact the after-sales support department.

Refer to the manual that comes with the test kits.

Mini test kit and portable test kit

The test connector is used to connect the mini or the portable test kit to check that the control unit is operating correctly.




04443728AA - 01/2009 Schneider Electric


89

Tripping curves

Long-time I^2t , short-time and instantaneous protection Micrologic 5.0 H, 6.0 H, 7.0 H




Long-time Idmtl, short-time and instantaneous protection Micrologic 5.0 H, 6.0 H, 7.0 H



Tripping curves

Ground-fault protection - Micrologic 6.0 H



Voltage measurements

Micrologic H is equipped with a three-phase voltage power supply that, with respect to the distribution system, may be considered a delta load. The three-phase power supply reinjects voltage on an open phase.

The voltage-protection functions react as indicated below.

Minimum-voltage protection

This function is based on the measurement of the phase-to-phase voltages.

In diagrams 1, 3 and 4 on the next page, a fuse has blown. The control unit reinjects voltage on the failed phase and measures a phase-to-phase voltage higher than the actual voltage.

The phase-to-neutral voltage should be zero, but the value measured is not zero.

In diagram 2, the phase-to-neutral voltage is effectively zero and the measurement indicates zero as well.

By limiting the pickup threshold of the minimum-voltage protection to the 80% - 100% range of the rated distribution-system voltage, the differences between the real voltages and the measured values are not significant and Micrologic will operate under all circumstances in the expected manner.

Voltage-unbalance protection

This function is based on the measurement of the phase-to-phase voltages.

In diagrams 1, 3 and 4 on the next page, a fuse has blown. The control unit reinjects voltage on the failed phase and measures a phase-to-phase voltage higher than the actual voltage.

The phase-to-neutral voltage should be zero, but the value measured is not zero.

In diagram 2, the phase-to-neutral voltage is effectively zero and the measurement indicates zero as well.

By limiting the pickup threshold of the voltage-unbalance protection to the 0% - 20% range, the differences between the real voltages and the measured values are not significant and Micrologic will operate under all circumstances in the expected manner.


Phase failure

Detection of phase failure is not possible on the basis of the minimum-voltage and voltage-unbalance protection functions.


The Micrologic power supply requires at least two phases (between 100 and 690 V).

In diagrams 1, 3 and 4, if two phases have failed, Micrologic H measures for the three phases the value of the single voltage present (e.g. U12 = U23 = U31 = 410 V).

Voltage measurements



Zone selective interlocking (ZSI)



Caution!

If the protection function is not used on circuit breakers equipped for ZSI protection, a jumper must be installed to short terminals Z3, Z4 and Z5. If the jumper is not installed, the short-time and ground-fault tripping delays are set to zero, whatever the position of the adjustment dial.

Terminals Z1 to Z5 correspond to the identical indications on the circuit-breaker terminal blocks.

Operating principle

■ A fault occurs at point A

Downstream device no. 2 clears the fault and sends a signal to upstream device no. 1, which maintains the short-time tripping delay tsd or the ground-fault tripping delay ts to which it is set.

■ A fault occurs at point B

Upstream device no. 1 detects the fault. In the absence of a signal from a downstream device, the set time delay is not taken into account and the device trips according to the zero setting. If it is connected to a device further upstream, it sends a signal to that device, which delays tripping according to its tsd or tg setting.

Note

on device no. 1, the tsd and tg tripping delays must not be set to zero because this would make discrimination impossible.

Connections between control units

A logic signal (0 or 5 volts) can be used for zone selective interlocking between the upstream and downstream circuit breakers.

- Micrologic 5.0 A, 6.0 A, 7.0 A
- Micrologic 5.0 P, 6.0 P, 7.0 P
- Micrologic 5.0 H, 6.0 H, 7.0 H.


An interface is available for connection to previous generations of trip units.

Wiring

- Maximum impedance: 2.7 Ω / 300 metres
- Capacity of connectors: 0.4 to 2.5 mm²
- Wires: single or multicore
- Maximum length: 3000 metres
- Limits to device interconnection:

 $\hfill \Box$ the common ZSI - OUT (Z1) and the output ZSI - OUT (Z2) can be connected to a maximum of ten inputs

 $\ \square$ a maximum of 100 devices may be connected to the common ZSI - IN (Z3) and to an input ZSI - IN CR (Z4) or GF (Z5).



Test

The portable test kit may be used to check the wiring and operation of the zone selective interlocking between a number of circuit breakers.

Power supply

Caution!

It is advised to use the AD power-supply module rather than an off-the-shelf 24 V power supply to ensure Class II insulation on the front panel of the Micrologic H control unit.

The power supply must have the following characteristics:

- output voltage 24 V DC
- DC ripple less than 5%
- power rating 5 W / 5 VA
- Dielectric withstand (input/output):

3 k\/ rms

AD power-supply module

The AD power-supply module provides auxiliary 24 V DC power for the control-unit functions listed below:

- graphic display:
- □ device OFF or not supplied

□ the long-time, short-time, instantaneous and ground-fault protection functions operate under all circumstances on their own power

■ activation of an M2C programmable contact

The AD power-supply module is required to assign an M2C programmable contact to an alarm.

The AD power-supply module can supply the following voltages:


- 110 V AC
- 220 V AC
- 380 V AC
- 24 / 30 V DC
- 48 / 60 V DC
- 125 V DC.

Battery module


Use of a BAT battery module, mounted in series with the AD power-supply module, ensures a continous supply of 24 V DC power for 12 hours if the AD module fails.

Wiring diagrams


□ reliable or backed-up auxiliary system



□ auxiliary system without back-up



■ Supply with the MC6 module



Power supply

Using the AD power-supply module

The 24 V DC external power-supply (AD module) is required for certain operating configurations as indicated in the table below:

- yes means the power supply is required
- no means it is not required.

Circuit breaker	Closed	Open	Open	
AC power present for Micrologic H	yes	yes	no	
M2C, M6C programmable-contacts option	yes	yes	yes	
Display function	no	no	yes	
Time-stamping function	no	no	no	
Circuit-breaker status indications and control via communications bus	no	no	no	
Identification, settings, operation and maintenance aids via communications bus	no	no	yes	

- If the 24 V DC external power supply (AD module) is used, the maximum cable length between 24 V DC (G1, G2) and the control unit (F1-, F2+) must not exceed 10 metres
- The communications bus requires its own 24 V DC power source (E1, E2). This source is not the same as the 24 V DC external power-supply module (F1-, F2+).

Selection of the voltage-measurement inputs

The voltage-measurement inputs are standard equipment on the downstream connectors of the circuit breaker.

It is possible to measure distribution-system voltage externally using the PTE external voltage-measurement input option.

With this option, the internal voltage-measurement inputs are disconnected. The PTE option is required for voltages greater than 690 V (in which case a voltage transformer is required).

When the PTE option is implemented, the supply circuit of the voltage-measurement input must be protected against short-circuits. Installed as close as possible to the busbars, this protection function is ensured by a P25M circuit breaker (1 A rating) with an auxiliary contact (cat. no. 21104 and 21117).

The supply circuit of the voltage-measurement input is reserved exclusively for the control unit and must never be used to supply other circuits.

Changing the long-time rating plug

Select the long-time rating plug

A number of long-time rating plugs are available for Micrologic H control units.

Part number	Setting range f	Setting range for the Ir value		
33542	standard	0.4 to 1 x Ir		
33543	low setting	0.4 to 0.8 x lr		
33544	high setting	0.8 to 1 x Ir		
33545	without long-time prote ■ Ir = In for the short-t ■ Frequency protectio ■ Load shedding / rec	time protection setting		


Caution!

Following any modifications to the long-time rating plug, all control-unit protection parameters must be checked.


Change the long-time rating plug

Proceed in the following manner.

- 1. open the circuit breaker
- 2. open the protective cover of the control unit



3. completely remove the long-time rating plug screw




Caution!


If no long-time rating plug is installed, the control unit continues to operate under the following downgraded conditions:

- the long-time current setting Ir is 0.4
- the long-time tripping delay tr corresponds to the value indicated by the adjustment dial
- the earth-leakage protection function is disabled
- the voltage-measurement inputs are disconnected.

4. snap out the rating plug



- 5. clip in the new rating plug
- 6. refit the screw for the long-time rating plug
- 7. check and/or modify the control-unit settings



Thermal memory

Thermal memory

The thermal memory is the means to take into account temperature rise and cooling caused by changes in the flow of current in the conductors.

These changes may be caused by:

- repetitive motor starting
- loads fluctuating near the long-time protection settings
- repeated circuit-breaker closing on a fault.

Control units with a thermal memory record the temperature rise caused by each overload, even very short ones. This information stored in the thermal memory reduces the tripping time.

Micrologic control units and thermal memory

All Micrologic control units are equipped as standard with a thermal memory.

- For all protection functions, prior to tripping, the temperature-rise and cooling time constants are equal and depend depend on the tr tripping delay:
- $\hfill\Box$ if the tripping delay is short, the time constant is low
- □ if the tripping delay is long, the time constant is high.
- For long-time protection, following tripping, the cooling curve is simulated by the control unit. Closing of the circuit breaker prior to the end of the time constant (approximately 15 minutes) reduces the tripping time indicated in the tripping curves.

Short-time protection and intermittent faults

For the short-time protection function, intermittent currents that do no provoke tripping are stored in the Micrologic H memory.

This information is equivalent to the long-time thermal memory and reduces the tripping delay for the short-time protection.

Following a trip, the short-time tsd tripping delay is reduced to the value of the minimum setting for 20 seconds.

Ground-fault protection and intermittent faults

The ground-fault protection implements the same function as the short-time protection (see above).

Data available via the COM communications option

The COM communications option can be used to remotely access the Micrologic H measurement, setting, maintenance and protection values.

Measurements

- Currents
- □ instantaneous currents
- □ maximum and minimum instantaneous currents
- □ average instantaneous currents
- □ instantaneous-current unbalance per phase
- □ maximum and minimum instantaneous-current unbalance per phase
- Demand current
- □ demand current per phase
- ☐ maximum and minimum demand current per phase since last reset
- □ prediction of demand current per phase
- □ time-stamping of demand-current maximums and minimums
- Voltages
- □ phase-to-neutral and phase-to-phase voltages
- □ average phase-to-neutral and phase-to-phase voltages
- □ phase-to-neutral and phase-to-phase voltage unbalance
- □ maximum and minimum phase-to-neutral and phase-to-phase voltage unbalance
- Active, reactive and apparent power per phase
- Demand power
- □ demand power per phase
- □ maximum and minimum demand power per phase since last reset
- □ maximum and minimum recommended demand power per phase
- □ time-stamping of demand-power maximums and minimums
- Energy
- □ total active and reactive energy
- □ positively incremented energy
- □ negatively incremented energy
- System frequency
- Power factor
- Reset date of demand currents, demand power and energy
- Power quality indicators:
- □ instantaneous measurements together with maximums and minimums:
- fundamental apparent currents
- fundamental phase-to-neutral and phase-to-phase voltages
- fundamental rms currents
- fundamental active, reactive and apparent power per phase and total
- distortion power per phase and total
- THD and thd of the phase-to-neutral and phase-to-phase voltages - THD and thd of the currents
- phase angle between the voltages and the currents
- K factors
- peak voltages
- peak currents
- phase angle between the voltages
- K factors averages
- □ demand K factors:
- demand K factors per phase
- maximum demand K factor per phase since last reset
- prediction of demand K factors
- time-stamping of demand K factor maximums per phase
- harmonics:
- phase-to-neutral and phase-to-phase voltage harmonic amplitudes
- current harmonic amplitudes
- phase-to-neutral and phase-to-phase voltage harmonic phase angle
- current harmonic phase angle
- $\hfill\square$ monitoring of electrical parameters
- □ dates of last resets of minimums and maximums
- □ waveform capture
- □ event history file in the measurement module
- ☐ minimum and maximum file with time-stamping
- ☐ maintenance file in the measurement module
- minimum and maximum reset counters with time-stamping
- maximum demand-current reset counters with time-stamping
- maximum demand-power reset counters with time-stamping
- energy reset counters with time-stamping.

Data available via the COM communications option

Setup / Maintenance Setting of the control-unit date and time

- Password for the measurement module
- Control-unit ID code
- Control-unit ID name
- Selection of the measurement calculation algorithm
- Sign convention for the active power
- Total-energy measurement mode
- Interval for the demand-current calculation window
- Power quality indication
- Demand-power calculation mode
- Interval for the demand-power calculation window
- Battery-charge indication
- Trip and alarm histories
- Operation counter and contact-wear indicator
- Assignment and setup of programmable contacts
- Event log and maintenance register
- Power factor sign conventions
- Monitoring parameters
- Monitoring priorities levels
- Waveform capture.

Protection

- Circuit-breaker rated current
- Type of neutral protection
- Long-time I²t protection settings
- Long-time Idmtl protection settings
- Short-time protection settings
- Instantaneous-protection settings ■ Ground-fault protection settings
- Earth-leakage protection settings
- Current-unbalance, I = alarm and maximum-current protection settings
- Voltage-protection settings
- Setting for other protection functions.

Threshold and time-delay settings

Long-time I²t and Idmtl protection

Туре	Range	Factory setting	Step	Accuracy
Ir current setting	0.4 to In	maximum	1 A	1.05 to 1.20 Ir
tr tripping delay	0.5 to 24 s	maximum	0.5 s	-20 %, +0 %

Short-time protection

Туре	Range	Factory setting	Step	Accuracy
lsd pickup	1.5 to 10 Ir	maximum	10 A	±10 %
tsd tripping delay	0 - 0.1 - 0.2 - 0.3 - 0.4 s	maximum	0.1 s	

Instantaneous protection

Туре	Range	Factory setting	Step	Accuracy
li pickup	2 to 15 In or off	maximum	10 A	±10 %

Ground-fault protection on Micrologic 6.0 H

Type	Range	Factory setting	Step	Accuracy
lg pickup	depends on rating	maximum	1 A	±10 %
tg tripping delay	0 - 0.1 - 0.2 - 0.3 - 0.4 s	maximum	0.1 s	

Earth-leakage protection on Micrologic 7.0 H

101

Туре	Range	Factory setting	Step	Accuracy
l∆n pickup		maximum	0.1 A	-20 %, +0 %
∆t tripping delay	60 -140 - 230 - 350 - 800 ms	maximum	1 setting	

Neutral protection

Туре	Range	Factory setting
Three-pole device	Off, N/2, N, 1.6 x N	off
Four-pole device	Off, N/2, N	N/2

04443728AA - 01/2009 Schneide

Threshold and time-delay settings

Current protection

		•		
Type	Range	Factory setting	Step	Accuracy
Current unbalance I un	bal			
Pickup threshold	5 % to 60 %	60 %	1 %	-10 %, +0 %
Dropout threshold	5 % of pickup threshold	pickup threshold	1 %	-10 %, +0 %
Pickup time delay	1 s to 40 s	40 s	1 s	-20 %, +0 %
Dropout time delay	10 s to 360 s	10 s	1 s	-20 %, +0 %
Ground-fault I				
Pickup threshold	20 A to 1200 A	120 A	1 A	±15 %
Dropout threshold	20 A to pickup threshold	pickup threshold	1 A	±15 %
Pickup time delay	1 s to 10 s	10 s	0.1 s	-20 %, +0 %
Dropout time delay	1 s to 10 s	1 s	0.1 s	-20 %, +0 %
Earth-leakage I \(\frac{1}{2} \) alarm	l			
Pickup threshold	0.5 A to 30 A	30 A	0.1 A	-20 %, +0 %
Dropout threshold	0.5 A to pickup threshold	pickup threshold	0.1 A	-20 %, +0 %
Pickup time delay	1 s to 10 s	10 s	0.1 s	-20 %, +0 %
Dropout time delay	1 s to 10 s	1 s	0.1 s	-20 %, +0 %
Maximum current T1 ma	ax, T2 max, T3 max, TN max			
Pickup threshold	0.2 In to In	In	1 A	±6.6%
Dropout threshold	0.2 In to pickup threshold	pickup threshold	1 A	±6.6%
Pickup time delay	15 s to 1500 s	1500 s	1 s	-20 %, +0 %
Dropout time delay	15 s to 3000 s	15 s	1 s	-20 %, +0 %

Voltage protection

Туре	Range	Factory setting	Step	Accuracy
Minimum voltage U mi	n			
Pickup threshold	100 V to U max pickup threshold	100 V	5 V	-5 %, +0 %
Dropout threshold	pickup threshold to U max pickup threshold	pickup threshold	5 V	-5 %, +0 %
Pickup time delay	1.2 s to 5 s	5 s	0.1 s	-0 %, +20 %
Dropout time delay	1.2 s to 36 s	1.2 s	0.1 s	-0 %, +20 %
Maximum voltage U ma	ax			
Pickup threshold	U min pickup threshold to 1200 V	725 V	5 V	-0 %, +5 %
Dropout threshold	100 V to pickup threshold	pickup threshold	5 V	-0 %, +5 %
Pickup time delay	1.2 s to 5 s	5 s	0.1 s	-0 %, +20 %
Dropout time delay	1.2 s to 36 s	1.2 s	0.1 s	-0 %, +20 %
Voltage unbalance U u	nbal			
Pickup threshold	2 % to 30 %	30 %	1 %	-20 %, +0 %
Dropout threshold	2 % to pickup threshold	pickup threshold	1 %	-20 %, +0 %
Pickup time delay	1 s to 40 s	40 s	1 s	-20 %, +0 %
Dropout time delay	10 s to 360 s	10 s	1 s	-20 %. +0 %

Threshold and time-delay settings

Other protection

Туре	Range	Factory setting	Step	Accuracy
Reverse power rP max				
Pickup threshold	5 to 500 kW	500 kW	5 kW	±2.5%
Dropout threshold	5 kW to pickup threshold	pickup threshold	5 kW	±2.5%
Pickup time delay	0.2 s to 20 s	20 s	0.1 s	-0 %, +20 % ⁽¹⁾
Dropout time delay	1 s to 360 s	1 s	0.1 s	-0 %, +20 %
Maximum frequency F max				
Pickup threshold	F min pickup threshold to 440 Hz	65 Hz	0.5 Hz	±0.5 Hz
Dropout threshold	45 Hz to pickup threshold	pickup threshold	0.5 Hz	±0.5 Hz
Pickup time delay	1.2 s to 5 s	5 s	0.1 s	-0 %, +20 % ⁽²⁾
Dropout time delay	1.2 s to 36 s	1.2 s	0.1 s	-0 %, +20 % ⁽²⁾
Minimum frequency F min				
Pickup threshold	45 Hz to F max pickup threshold	45 Hz	0.5 Hz	±0.5 Hz
Dropout threshold	pickup threshold to F max pickup threshold	pickup threshold	0.5 Hz	±0.5 Hz
Pickup time delay	1.2 s to 5 s	5 s	0.1 s	-0 %, +20 % ⁽²⁾
Dropout time delay	1.2 s to 36 s	1.2 s	0.1 s	-0 %, +20 % ⁽²⁾
Phase rotation				
Pickup threshold	Ph1, Ph2, Ph3 or Ph1, Ph3, Ph2	Ph1, Ph2, Ph3	none	none
Dropout threshold	pickup threshold	pickup threshold	none	none
Pickup time delay	0.3 s	0.3 s	none	-0 %, +50 %
Dropout time delay	0.3 s	0.3 s	none	-0 %, +50 %
(4) . 00 0/				

^{(1) +30 %} on dial 0.2 s (2) +30 % up to 1.5 s

Load shedding and reconnection

Туре	Range	Factory setting	Step	Accuracy
Current I				
Pickup threshold	50 % to 100 % Ir	100 % Ir	1 %	±6 %
Dropout threshold	30 % Ir to shedding threshold	shedding threshold	1 %	±6 %
Pickup time delay	20 % to 80 % tr	80 % tr	1 %	-20 %, +0 %
Dropout time delay	10 s to 600 s	10 s	1 s	-20 %, +0 %
Power P				
Pickup threshold	200 kW to 10 000 kW	10 000 kW	50 kW	±2.5 %
Dropout threshold	100 kW to shedding threshold	shedding threshold	50 kW	±2.5 %
Pickup time delay	10 s to 3600 s	3600 s	10 s	-20 %, +0 %
Dropout time delay	10 s to 3600 s	10 s	10 s	-20 %, +0 %

Other settings

M2C / M6C contacts

Type	Range	Factory setting	Step
Time-delay latching time delay	1 - 360 s	360 s	1 s

Micrologic setup

Type	Range	Factory setting	Step
Language	German English US English UK Italian French Spanish Chinese	English UK	·
Date / time			1 s
Circuit-breaker selection		"no def"	
Neutral TC		no TC	
VT ratio			
Primary voltage	min. 100 V, max. 1150 V	690 V	1 V
Secondary voltage	min. 100 V, max. 690 V	690 V	1 V
System frequency	50/60 Hz or 400 Hz	50/60 Hz	

Measurement setup

	-		
Туре	Range	Factory setting	Step
System type	3 Ф, 3 w, 3 СТ	3 Ф, 4 w, 4 СТ	
	3 Ф, 4 w, 3 СТ		
	3 Ф, 4 w, 4 СТ		
Demand-current			
Calculation method	thermal or	block interval	
	block interval		
Type of window	fixed or sliding	sliding	
Calculation interval	5 to 60 minutes	15 minutes	1 minute
Demand-power			
Calculation method	thermal or	block interval	
	block interval or		
	sync. to comms		
Type of window	fixed or sliding	sliding	
Calculation interval	5 to 60 minutes	15 minutes	1 minute
Power sign	P+	P+	
-	P-	(flow from top to	
		bottom)	
Sign convention	IEEE	IEEE	
	IEEE alternate		
	IEC		

Communication setup

Туре	Range	Factory setting
Com parameter	MODBUS	
Adress	1-47	47
Baud rate	9600 to 19200 bauds	19200 bauds
Parity	even none	even
Remote settings Access authorisation	yes / no	yes
Access code	0000 to 9999	0000
Remote control	manual automatic	automatic

Protection setup

Туре	Range	Factory setting
Current protection voltage protection other protection	alarm / trip / OFF	OFF

Measurement setting ranges and accuracy

■ The accuracy of the current measurements depends on both the value displayed (or transmitted) and the circuit-breaker rating, where:

Accuracy = 0.5 % In + 1.5 % reading

Example:

For a circuit breaker with a 4000 A rating and a current displayed on Micrologic of 49 A, the accuracy is: $0.5 \% \times 4000 + 1.5 \% \times 49 = \pm 21 A$


Measurement setting ranges and accuracy


_		
Туре	Range	Accuracy at 25 °C
Instantaneous current		
11, 12, 13	0.05 x In to 20 x In	±1.5 %
IN	0.05 x In to 20 x In	±1.5 %
	0.05 x In to In	
<u>I</u> <u>+</u> ground		±10 %
I earth leakage	0 to 30 A	±1.5 %
11 max, I2 max, I3 max	0.05 x In to 20 x In	±1.5 %
IN max	0.05 x In to 20 x In	±1.5 %
I ≟ max ground	0.05 x In to In	±10 %
I ≟ max earth leakage	0 to 30 A	±1.5 %
Demand current		
<u>11, 12, 13</u>	0.05 x In to 20 x In	±1.5 %
ĪN	0.05 x In to 20 x In	±1.5 %
11 max, 12 max, 13 max	0.05 x In to 20 x In	±1.5 %
IN max	0.05 x In to 20 x In	±1.5 %
Phase-to-phase voltages	0.00 % to 20 %	= 1.0 /s
U12	170 to 1150 V	±0.5 %
U23	170 to 1150 V	
		±0.5 %
U31	170 to 1150 V	±0.5 %
Phase-to-neutral voltages		
V1N	100 to 1150 V	±0.5 %
V2N	100 to 1150 V	±0.5 %
V3N	100 to 1150 V	±0.5 %
Average voltage		
U avg	170 to 1150 V	±0.5 %
Voltage unbalance		
U unbal	0 to 100 %	±0.5 %
Instantaneous power		
P	0.015 to 184 MW	±2 %
Q	0.015 to 184 Mvar	±2 %
S	0.015 to 184 MVA	±2 %
Power factor		,,
PF	-1 to +1	±2 %
	-110 11	12 /0
Demand power	0.0451, 4041404	.0.0/
<u>P</u>	0.015 to 184 MW	±2 %
Q	0.015 to 184 Mvar	±2 %
<u>S</u>	0.015 to 184 MVA	±2 %
P max	0.015 to 184 MW	±2 %
Q max	0.015 to 184 Mvar	±2 %
S max	0.015 to 184 MVA	±2 %
Total energy		
E.P	-10 ¹⁰ GWh to +10 ¹⁰ GWh	±2 %
E.Q	-1010 Gvarh to +1010 Gvarh	±2 %
E.S	-10 ¹⁰ GVAh to +10 ¹⁰ GVAh	±2 %
Total energy in		
E.P	-10 ¹⁰ GWh to +10 ¹⁰ GWh	±2 %
E.Q	-10 ¹⁰ Gyarh to +10 ¹⁰ Gyarh	±2 %
Total energy out		
E.P	-10 ¹⁰ GWh to +10 ¹⁰ GWh	±2 %
E.Q	-10 ¹⁰ Gvarh to +10 ¹⁰ Gvarh	±2 %
Frequency	10 Gvaill to 110 Gvaill	12 /0
F	45 Hz to 440 Hz	±0.1 %
	43 112 10 440 112	10.1 /8
Fundamentals	0.005 la ta 4.5 la	· 4 F 0/ (1)
1	0.005 x ln to 1.5 x ln	±1.5 % ⁽¹⁾
U	30 to 1150 V	±0.5 %
P, Q, S	0.15 to 13.8 kW	±2 %
THD, thd		
1	2 to 1000%	±5 %
U	2 to 1000%	±5 %
FFT		
<u> </u>	0 to 1000%	±5 %
U	0 to 1000%	±5 %
(1) Over the range 0.7 x In to 1.5	v	


105


(1) Over the range 0.7 x In to 1.5 x

Power factor sign conventions









04443728AA - 01/2009 Schneider 107

A Activation Active, reactive, apparent energy Active, reactive, apparent power AD power-supply module Address Alarm	27, 28, 29, 30, 44 32, 75 73 95 58 44, 47
Alarm history	46, 85
B Baud rate Buttons	58 5, 6
C Circuit-breaker selection COM communication option Contact Contact wear Control unit identification Control-unit battery Cos φ Crest factor Current demand calculation	53 49, 58, 99 45, 50 86 4 5, 87 40 41 31, 55
D Date and time Demand current Demand power Digipact Direction of power flow Distortion factor Distortion power Dropout DT	52 55, 69 32, 56 58 54 41 41 27, 28, 29, 30, 44 23, 61
$\mbox{\bf E}$ Earth-leakage protection Earth-leakage protection tripping delay Δ EIT	26 26 23, 61
F F max F min Fault Frequency FTT Full neutral protection Fundamental Graphic display Ground-fault / Earth-leakage fault protection test Ground-fault protection	29, 64 29, 64 84 32, 54, 82 42, 80 25, 63 77 5 88 26
H Half neutral protection Harmonics History, setup and maintenance menu HVF	25, 63 33 13, 18 6, 23
I	62 27, 64 27 27, 64 64 26 22, 60 23, 61 26 24 5 68 24 22, 23 24

C C factor	41
Language Latching Lead seal for cover LEDs Load shedding / reconnection Long-time 2t protection Long-time dmt protection Long-time plug	52 45, 50 5 5, 47, 87 30, 66 22 23 5, 97
M M2C / M6C Main screen Maximum demand current Maximum demand power Maximum instantaneous current Metering menu ModBus	45, 50 12, 68 31, 70 32, 74 31, 68 13, 14 58
Negatively incremented energy Neutral CT Neutral protection Neutral protection setting No neutral protection	32, 75 63 23, 25 11 25, 63
Deration counter Oversized neutral protection	86 25, 63
Parity Phase rotation Phase sequence Phase-to-neutral and phase-to-phase voltage Portable test kit Positively incremented energy Power demand calculation Power factor Power sign Power supply Protection menu	58 29, 31, 64 31, 72 31, 71 88 32, 75 32, 56 40 54 95 13, 20
Remote control Remote settings Resetting the alarms and fault indications Resetting the contacts Resetting the energy values Resetting the maximum demand current values Resetting the maximum demand power values Resetting the maximum instantaneous current values Resetting the operation counter RMS current ms voltage P max	59 58 84 45, 50 75 70 74 68 86 37 37 29, 64
Self-protection Setting dials Short-time protection Sign convention SIT System frequency System type	5, 48 5, 6 24 106 23, 61 54 55

109

04443728AA - 01/2009 Schneider Flectric

Т	
Tab	7
Temperature	22, 48, 98
Test connector	5, 88
tg tripping delay	26
THD	37, 78
thd	39, 79
Thermal memory	22, 98
tr tripping delay Transformation ratio	22, 23 54
Trip	44
Trip history	46, 85
Tripping curves	90
tsd tripping delay	24
U U max U min U unbal	28 28, 92 28, 71, 92
V	00.04
VIT Voltage U avg	23, 61 28, 31
voltage o avg	20, 31
w	
Waveform	43
Waveform capture	43, 76
Z	•
Zone selective interlocking	94

Notes

04443728AA - 01/2009 Schneider 111

Notes

RCS Nanterre 954 503 439 Capital social 896 313 776 € www.schneider-electric.com

As standards, specifications and designs change from time to time, please ask for confirmation of the information given in this publication.



This document has been printed on ecological paper

Design: Schneider Electric Photos: Schneider Electric Printed:

© 2009 - Schneider Electric - Tous droits réservés